

TMC4670 Datasheet

IC Version V0.99 | Document Revision V0.91 • 2016-Nov-09

The TMC4670 is a field oriented control (FOC) servo controller for torque control, velocity control, and positioning. Integrated ADCs, position sensor interfaces, position interpolators, enables a servo controller with a couple components.




Features

- Field Oriented Control (FOC) w/ Servo Controller
- Torque Control (FOC), Velocity Control, Position Control
- Feed Forward Offsets
- Integrated ADCs
- Encoder Engine: Hall analog/digital, Encoder analog/digital, 2nd digital Encoder
- Supports 3-Phase PMSM (FOC3) and 2-Phase Stepper Motors (FOC2)
- PWM Engine including SVPWM
- SPI Communication Interface

Applications

- Robotics
- Pick and Place Machines
- Semiconductor Handling
- Factory Automation
- E-Mobility
- Laboratory Automation
- Blowers
- Pumps

Simplified Block Diagram



Contents

1 Order Codes	4
2 Functional Summary	5
3 Functional Description	6
3.1 Functional Blocks	6
3.2 Communication Interface	7
3.2.1 SPI Slave User Interface	7
3.3 Register Bank	8
3.3.1 Register Bank - Read and Write	8
3.3.2 Register Access Datagram Examples	9
3.3.3 Identification of Silicon via Type, Version, Date, and Time	9
3.3.4 Read of RAW Inputs & RAW Outputs	9
3.4 Numerical Representation, Electrical Angle, Mechanical Angle, and Pole Pairs	9
3.4.1 Numerical Representation	9
3.4.2 N_POLE_PAIRS, PHI_E, PHI_M	10
3.4.3 Numerical Representation of Angles PHI	11
3.5 ADC Engine	12
3.5.1 Internal ADC	13
3.5.2 External ADC (LTC2351)	13
3.5.3 ADC Selector & ADC Scaler w/ Offset Correction	13
3.6 Encoder Engine	15
3.6.1 Open Loop Encoder	15
3.6.2 Incremental ABN Encoder	15
3.6.3 Secondary Incremental ABN Encoder	17
3.6.4 Digital Hall Sensor Interface with optional Interim Position Interpolation	17
3.6.5 Digital Hall Sensor - Interim Position Interpolation	18
3.6.6 Digital Hall together with Incremental Encoder	18
3.6.7 Analog Hall and Analog Encoder Interface (SinCos of 0°90° or 0°120°240°)	19
3.6.8 Analog Position Decoder (SinCos of 0°90° or 0°120°240°)	20
3.7 FOC23 Engine	20
3.7.1 PI(D) Controllers	20
3.7.2 PI(D) Controller Calculations	21
3.7.3 PI(D) Controller - Clipping	21
3.7.4 PI Flux & PI Torque	22
3.7.5 PI Velocity	22
3.7.6 P(I) Position	23
3.7.7 Inner FOC Control Loop - Flux & Torque	23
3.7.8 FOC Transformations and PI(D) for control of Flux & Torque	23
3.7.9 Motion Modes	24
3.8 PWM Engine	24
3.8.1 PWM Polarities	25
3.8.2 PWM frequency	25
3.8.3 PWM Resolution	25
3.8.4 PWM Modes	25
3.8.5 Brake-Before-Make (BBM)	25
3.8.6 Space Vector PWM (SVPWM)	26
4 Safety Functions	26
5 Register Map	27
6 Pinning	86



7 Package Dimensions	97
8 Supplemental Directives	98
8.1 Producer Information	98
8.2 Copyright	98
8.3 Trademark Designations and Symbols	98
8.4 Target User	98
8.5 Disclaimer: Life Support Systems	98
8.6 Disclaimer: Intended Use	98
8.7 Collateral Documents & Tools	99
9 Figures Index	100
10 Tables Index	101
11 Revision History	102
11.1 IC Revision	102
11.2 Document Revision	102

1 Order Codes

Order Code	Description	Size [mm ²]
TMC4670-BI	TMC4670 FOC Servo Controller IC	17 x 2.5
TMC4670-EVAL	TMC4670 Evaluation Board	85 x 79

Table 1: Order codes



2 Functional Summary

- **Field Oriented Control (FOC) Servo Controller**

- torque (and flux) control mode
- velocity control mode
- position control mode
- update rate 200 kHz (w/ 4 kHz velocity meter sampling frequency)

- **PI Controllers**

- programmable clipping of inputs and outputs of interim results
- error sum (error integral over time) clipping
- programmable target torque change in time ($d\text{TargetTorque}/dt$) limiter
- programmable circular ($\sqrt{U_D^2 + U_Q^2}$) limiter
- PI controller clipping status bit vector for real time Monitoring
- Feed Forward Offsets for Target Values

- **Supported Motor Types**

- FOC3 : three-phase permanent magnet synchronous motors (PMSM)
- FOC2 : two-phase stepper motors

- **ADC Engine with Offset Correction and Scaling**

- integrated 12 bit ADCs as analog interface for currents and analog encoders
- interface to external AD (LTC2351, 14 bit or 12 bit)
- ADC register to write externally sampled data via SPI communication interface

- **Encoder Engine**

- open loop position generator (programmable [rpm], [rpm/s]) for initial setup
- digital incremental encoder (ABN resp. ABZ, up to 5MHz)
- secondary digital incremental encoder
- digital hall sensor interface (H_1, H_2, H_3 resp. H_U, H_V, H_W)
- digital hall sensor interface with interpolation of interim positions
- analog encoder/analog hall sensor interface (SinCos (0°, 90°) or 0°, 120°, 240°)
- position multi-turn counter (32 Bit)

- **PWM Engine including SVPWM**

- programmable PWM frequency within range 25kHz ... 200kHz
- programmable Brake-Before-Make (BBM) times (high side, low side) 0ns ... 2.5μs in 10ns steps
- PWM auto scaling for transparent change of PWM frequency during motion

- **SPI Communication Interface**

- 40 bit datagram length (1 ReadWrite bit + 7 address bits + 32 data bits)
- immediate SPI read response (register read access by single datagram)

- **Supply Voltages** 3.3V, 2.5V, 1.2V

- **IO Voltage** 3.3V

- **Clock Frequency** 25MHz

- **Package** 17mm x 17mm BGA w/ 1mm ball pitch



3 Functional Description

TMC4670 is a fully integrated controller for field-oriented control (FOC) of either one 2-phase stepper motor (FOC2) or one 3-phase brushless motor (FOC3). It contains the complete control loop core architecture (position, velocity, torque) as well as required peripheral interfaces for communication with an application controller, for feedback (digital encoder, analog interpolator encoder, digital Hall, decoder Hall position interpolator, analog inputs for current and voltage measurement), and helpful additional IO. It supports highest control loop speed and PWM frequencies.

The TMC4670 is the building block for the user application that takes care of all real time critical tasks of field oriented motor control. It decouples the real time field oriented motor control and its real sub-tasks as current measurement, real time sensor signal processing, real time PWM signal generation from the user application layer as outlined by figure 17.




Figure 1: Hardware FOC Application Diagram

3.1 Functional Blocks

Application interface, register bank, ADC engine, encoder engine, FOC torque PI controller, velocity PI controller, position P controller, and PWM engine form the TMC4670. The TMC4670 supports 3-phase PMSM motors (FOC3) and 2-phase PMSM stepper motors (FOC2).




Figure 2: Hardware FOC Block Diagram



The ADC engine interfaces integrated ADC channels and maps raw ADC values to signed 16 bit (s16) values for the inner FOC current control loop based on programmable offset and scaling factors. The FOC torque PI controller forms the inner base component including required transformations (Clark, Park, inverse Park, inverse Clark). All functional blocks are pure hardware.

3.2 Communication Interface

The TMC4670 is equipped with an SPI interface for access to all registers of the TMC4670.

3.2.1 SPI Slave User Interface

The SPI of the TMC4670 for the user application has an easy command and control structure. The TMC4670 user SPI acts as a slave. The SPI datagram length is 40 bit with up to 2Mbit/s. The MSB (bit#39) is sent first. The LSB (bit#0) is sent last. The MSB (bit#39) is the WR_E not READ (WRnRD) bit. The bits (bit#39 to bit#32) are the address bits (ADDR). Bits (bit#31) to (bit#0) are (up to) 32 data bits. The SPI of the TMC4670 immediately responds within the actual SPI datagram on read and write for ease-of-use communication.




Figure 3: SPI Timing

SPI Interface Timing		Characteristics, fCLK = 25MHz					
Parameter	Symbol	Condition	Min	Typ	Max	Unit	
SCK valid before or after change of nSCS	t_{CC}		250			ns	
nSCS high time	t_{CSH}		250			ns	
nSCS low time	t_{CSL}		250			ns	
SCK high time	t_{CH}		250			ns	
SCK low time	t_{CL}		250			ns	
SCK low time	t_{CL}		250			ns	
SCK frequency	f_{SCK}				2	MHz	
MOSI setup time before rising edge of SCK	t_{DU}		250			ns	
MOSI hold time after falling edge of SCK	t_{DH}		250			ns	
MISO data valid time after falling edge of SCK	t_{DO}				10	ns	

Table 2: SPI Timing Parameter

40 BIT DATAGRAM		
8 BIT ADDR	32 DATA	
WRnRD	7 BIT ADDR	32 DATA

Figure 4: SPI Datagram Structure

3.3 Register Bank

1 Info

This section gives a functional description as an overview. The section 5 starting page 27 gives the detailed description of each register.

The register bank is the interface to the user application. Each register of the TMC4670 has 8 bit address followed by up to 32 data bits. Some addresses hold more than one data registers for simultaneous access or composed control bit vectors. Section 5 page 27 describes all registers in detail.

During initialization, the user writes parameters into associated registers. These parameters are scaling factors and offsets, sensor configuration parameters, limits for clipping, selections, P and I parameters for the FOC torque controller, P and I parameters for velocity controller, and P parameter for the position controller.

During application, the user writes application parameters into associated registers. These are - depending on the motion mode - target torque, target velocity, or target position.

The TMC4670 has direct access registers and indirect access registers. Most registers are direct access registers with read or write access by a single datagram. Some less often used registers (e.g. silicon version registers, internal values for read out) are accessed via two registers: address register and data register. The address register selects the address, the second register holds the data.

3.3.1 Register Bank - Read and Write

From the access point of view there are two kind of registers: read-only and read-write. The most significant bit (MSB) of each register access datagram defines read (=0) or write (=1). So, there are 128 read addresses ($0x00_h \dots 0x7F_h$) and 128 write addresses ($0x80_h \dots 0xFF_h$) available. The TMC4670 ignores write accesses to read-only registers.

- Fixed Read Only Register (e.g. SILICON_TYPE, SILICON_VERSION, SILICON_DATE, SILICON_TIME)
- Read Only Register for internal values (e.g. scaled ADC values)
- Read Only Register for external Signals (e.g. ADC raw values, ABN encoder inputs, Hall signal inputs)
- Read Write Register for configurations (e.g. P and I parameter of PI controller, clipping parameters)
- Read Write Register for target values (e.g. target torque, target velocity, target position)
- Dual Ported Read Write Register (e.g. encoder count, actual position)



3.3.2 Register Access Datagram Examples

`0x0100000000h` : reads data from address `0x01h`

`0x8123456789h` : writes data `0x23456789h` to address `0x01h`

3.3.3 Identification of Silicon via Type, Version, Date, and Time

The read-only registers of silicon type, version with date and time identify the type of the silicon, the version of the silicon together with unique date stamp and time stamp. This enables the automatic identification of IC and version and enable the automatic handling of different IC and different versions.

3.3.4 Read of RAW Inputs & RAW Outputs

For ease-of-use while setting up the configuration, raw input signals and raw output signals are mapped into the register bank for user read out. With this, the user can initially check without a scope that the desired signals come into the TMC4670 as expected. Examples of readable raw input signals are digital Hall signals and incremental encoder signals.

3.4 Numerical Representation, Electrical Angle, Mechanical Angle, and Pole Pairs

The TMC4670 uses different numerical representations for different parameters, measured values, and interim results. The terms electrical angle PHI_E, mechanical angle PHI_M, and number of pole pairs (N_POLE_PAIRS) of the motor are important for setup of FOC. This section describes the different numerical representations of parameters and terms.

3.4.1 Numerical Representation

The TMC4670 uses singed and unsigned values of different length and fixed point representation for parameters that require a non-integer granularity.

Symbol	Description	Min	Max
u16	unsigned 16 bit value	0	65535
s16	singed 16 bit values, 2'th complement	-32767	32767
u32	unsigned 32 bit value	0	$2^{32} = 4294967296$
s32	singed 32 bit values, 2'th complement	-2147483647	$2^{31} - 1 = 2147483647$
q8.8	singed fix point value with 8 bit interger part and 8 bit fractional part	-32767/256	32767/256
q4.12	singed fix point value with 4 bit interger part and 12 bit fractional part	-32767/4096	-32767/4096

Table 3: Numerical Representations

1 Info

Two's complement of n bit is $-2^{n-1} \dots -2^{n-11} - 1$. To avoid un-wanted overflow, the range is clipped to $-2^{n-1} + 1 \dots -2^{n-11} - 1$.

Because the zero is interpreted as a positive number for 2'th complement representation of interger n bit number, the smallest negative number is $-2^{(n-1)}$ where the largest positive number is $2^{(n-1)} - 1$. Using



the smallest negative number $-2^{(n-1)}$ might cause critical under-flow or over-flow. Internal clipping takes this into account by mapping $-2^{(n-1)}$ to $-2^{(n-1)} + 1$.

Hexadecimal Value	u16	s16	q8.8	q4.12
0x0000 _h	0	0	0.0	0.0
0x0001 _h	1	1	1 / 256	1 / 4096
0x0001 _h	2	2	2 / 256	2 / 4096
0x0080 _h	128	128	0.5	0.03125
0x0100 _h	256	256	1.0	0.0625
0x0200 _h	512	512	2.0	0.125
0x3FFF _h	16383	16383	16383 / 256	16383 / 4096
0x5A81 _h	23169	23169	23169 / 256	23169 / 4096
0x7FFF _h	32767	32767	32767 / 256	32767 / 4096
0x8000 _h	32768	-32768	-32768 / 256	-32768 / 4096
0x8001 _h	32769	-32767	-32767 / 256	-32767 / 4096
0x8002 _h	32770	-32766	-32766 / 256	-32766 / 4096
0xC001 _h	49153	-16383	-16383 / 256	-16383 / 4096
0xFFFFE _h	65534	-2	-2 / 256	-2 / 4096
0xFFFFF _h	65535	-1	-1 / 256	-1 / 4096

Table 4: Examples of u16, s16, q8.8, q4.12

The q8.8 and q4.12 are used for P and I parameters which are positive numbers but q8.8 and q4.12 are used as signed numbers. This is because these values are multiplied with signed error values resp. error integral values.

3.4.2 N_POLE_PAIRS, PHI_E, PHI_M

The parameter N_POLE_PAIRS defines the factor between electrical angle PHI_E and mechanical angle PHI_M of a motor (pls. refer figure 5).

A motor with one (1) pole pair turns once for each electrical period. A motor with two (2) pole pairs turns once for each two electrical periods. A motor with three (3) pole pairs turns once for each three electrical periods. A motor with four pole (4) pairs turns once for each four electrical periods.

The electrical angle PHI_E is relevant for the commutation of the motor. It is relevant for the torque control of the inner FOC loop.

$$\text{PHI}_E = \text{PHI}_M \cdot \text{N_POLE_PAIRS} \quad (1)$$

The mechanical angle PHI_M is primarily relevant for velocity control and for positioning. This is because one wants to control the motor speed in terms of mechanical turns and not in terms of electrical turns.



$$\text{PHI_M} = \text{PHI_E}/\text{N_POLE_PAIRS} \quad (2)$$

Different encoders give different kind of position angles. Analog hall sensors normally give the electrical position PHI_E that can be used for commutation. Analog encoders give - depending on their resolution - angles that have to be scaled first to mechanical angles PHI_M and to electrical angles PHI_E for commutation.




Figure 5: *N_POLE_PAIRS - Number of Pole Pairs*

3.4.3 Numerical Representation of Angles PHI

Electrical angles and mechanical angles are represented as 16 bit integer values. One full revolution of 360 deg is equivalent to $2^{16} = 65536$ steps. Any position coming from a sensor is mapped to this integer range. Adding an offset of PHI_OFFSET causes a rotation of an angle PHI_OFFSET/ 2^{16} . Subtraction of an offset causes a rotation of an angle PHI_OFFSET in opposite direction.




Figure 6: *Integer Representation of Angles with 16 Bit as s16 resp. u16*



Hexadecimal Value	u16	s16	PHI[°]	\pm PHI[°]
0x0000 _h	0	0	0.0	0.0
0x1555 _h	5461	5461	30.0	-330.0
0x2AAA _h	10922	10922	60.0	-300.0
0x4000 _h	16384	16384	90.0	-270.0
0x5555 _h	21845	21845	120.0	-240.0
0x6AAA _h	27306	27768	150.0	-210.0
0x8000 _h	32768	-32768	180.0	-180.0
0x9555 _h	38229	-27307	210.0	-150.0
0xAAAA _h	43690	-21846	240.0	-120.0
0xC000 _h	49152	-16384	270.0	-90.0
0xD555 _h	54613	-10923	300.0	-60.0
0xEAAA _h	60074	-5462	330.0	-30.0

Table 5: Examples of u16, s16, q8.8

The option of adding an offset is for adjustment of angle shift between motor and stator and rotor and encoder. Finally, the relative orientations between motor and stator and rotor and encoder can be adjusted by just one offset. Alternatively, one can set the counter position of an incremental encoder to zero on initial position. For absolute encoders one needs to use the offset to set an initial position.

3.5 ADC Engine

The ADC engine controls the sampling of different available ADC channels.

The FOC engine expects offset corrected ADC values, scaled into the FOC engine 16 bit (s16) fixed point representation. The integrated scaler and offsetter maps raw ADC samples of current measurement channels to 16 bit two's complement values (s16). Both, offset and scale calculations are signed. With this, the user can change the signs of current according to the application by the scaling factors.

The s16 scaled ADC values are available for read out from the register by the user. ADC samples for motor supply voltage (VM), MOSFET temperature, motor temperature, general purpose analog input (AIN) are only raw values without scaling.

- ADC samples of integrated ADC
- ADC samples from external ADC (LTC2351)
- ADC samples from external sources can be written into dedicated registers (ADC EXT)
- ADC values are for:
 - phase current measurement (most important task)
 - Supply voltage measurement (for monitoring or brake chopper)
 - Analog Hall signal measurement
 - analog Sine/Cosine encoder signal measurement
 - analog voltage input for MOS-FET temperature signal monitoring

- analog voltage input for motor temperature signal monitoring

Info

Wrong scaling factors or wrong offsets might cause damages when the closed current regulation is active. Integrated hardware limiters allow protection especially in the setup phase when using careful limits.

3.5.1 Internal ADC

The TMC4670 is equipped with internal ADCs with input voltage range of 0V ... 2.5V for current measurement, supply voltage measurement, analog hall signal measurement, analog encoder.

3.5.2 External ADC (LTC2351)

Alternatively to the integrated ADCs, the TMC4670 supports external SPI ADCs LTC2351 from Linear Technology for current measurements. This is intended for current sensing on separate power stages.

3.5.2.1 ADC RAW

The sampled raw ADC values are available for read out by the user. This is important during the system setup phase to determine offset and scaling factors.

3.5.2.2 ADC EXT

The user can write ADC values into the ADC EXT registers of the register bank from external ADC sources. For example it there are high precision ADC values available from an external ADC.

3.5.3 ADC Selector & ADC Scaler w/ Offset Correction

The ADC selector selects ADC channels for FOC. The 3-phase FOC used two of three ADC channels for measurement and calculates the third channel via Kirchhoff's Law from the scaled and offset corrected ADC values. The 2-phase FOC just used two ADC channels because for the 2-phase stepper motor the two phases are independent from each other.

Note

The Open Loop Encoder is useful for setup of ADC channel selection, scaling, and offset by turning a motor open loop.

The FOC23 Engine processes currents as 16 bit signed (s16) values. Raw ADC values are expanded to 16 bit width independent of their resolution. With this, each ADC is available for read out as a 16 bit number. The ADC scaler w/ offset correction is for pre-processing of measured raw current values. It might be used to map to own units (e.g. A or mA). For scaling, gains of current amplifiers, reference voltages, and offsets have to be taken into account.

Info

Raw ADC values generally are of 16 bit width independent of their real resolution.



Info

The job of the ADC scaler is to map raw ADC values to the 16 bit signed (s16) range and to center the values to zero by removing of offsets.




Figure 7: ADC Selector & Scaler w/ Offset Correction

ADC offsets and ADC scalers for the analog current measurement input channels need to be programmed into the associated registers. Each ADC_I_U, ADC_I_V, ADC_I_UX, ADC_I_WY, ADCSD_I_UX, ADCSD_I_WY, ADC_I0_EXT, ADC_I1_EXT is mapped either to ADC_I0_RAW or to ADC_I1_RAW by ADC_I0_SELECT and ADC_I1_SELECT.

In addition, the ADC_OFFSET is for conversion of unsigned ADC values into signed ADC values as required for the FOC.

$$\text{ADC_I0} = (\text{ADC_I0_RAW} + \text{ADC_I0_OFFSET}) \cdot \text{ADC_I0_SCALE} \quad (3)$$

$$\text{ADC_I1} = (\text{ADC_I1_RAW} + \text{ADC_I1_OFFSET}) \cdot \text{ADC_I1_SCALE} \quad (4)$$

For FOC3 the third current ADC_I2 is calculated via Kirchhoff's Law. This requires the correct scaling and offset correction before. For FOC2 there is no calculation of a third current.

The ADC_UX_SELECT selects one of the three ADC channels ADC_I0 ADC_I1, ADC_I2 for ADC_UX.

The ADC_V_SELECT selects one of the three ADC channels ADC_I0 ADC_I1, ADC_I2 for ADC_V.

The ADC_WY_SELECT selects one of the three ADC channels ADC_I0 ADC_I1, ADC_I2 for ADC_WY.

The For FOC3 the third current ADC_I2 is calculated via Kirchhoff's Law. This requires the correct scaling and offset correction before. For FOC2 there is no calculation of a third current.



The ADC_UX, ADC_V, ADC_WY are for the FOC3 (U, V, W). The ADC_UX, and ADC_WY (X, Y) are for the FOC2.

Note	The Open Loop Encoder is useful for setup of ADC channel selection, scaling, and offset by turning a motor open loop.
-------------	---

3.6 Encoder Engine

The encoder engine is an unified position sensor interface. It maps the selected encoder position information to electrical position (ϕ_e) and to mechanical position (ϕ_m) the electrical angle. Both are 16 bit values. The encoder engine maps single turn positions from position sensors to multi-turn position. The user can overwrite the these multi-turn position for initialization.

The different position sensors are the position sources for torque and flux control via FOC, for velocity control, and for position control. The PHI_E_SELECTION selects the source of the electrical angel ϕ_e for the inner FOC control loop. VELOCITY_SELECTION selects the source for velocity measurement. With ϕ_e selected as source for velocity measurement, one gets the electrical velocity. With the mechanical angle ϕ_m selected as source for velocity measurement one gets the mechanical velocity taking the set number of pole pairs (N_POLE_PAIRS) of the motor into account. Nevertheless, for high precision position it might be useful to do positioning based on the electrical angel ϕ_e .

3.6.1 Open Loop Encoder

For initial system setup the encoder engine is equipped with an open loop position generator. With one can turn the motor open-loop by specifying speed in rpm and acceleration in rpm/s together with a voltage UD_EXT in D direction. So, the open-loop encoder it is not a real encoder, it just gives positions as an encoder does. The open-loop decoder has a direction bit to define once the direction of motion for the application.

Note	The open loop encoder is useful for initial ADC setup, encoder setup, hall signal validation, and for validation of the number of pole pairs of a motor. The open loop encoder turns a motor open with programmable velocity in unit [RPM] with programmable acceleration in unit [RPM/s].
-------------	--

So, with the open loop encoder one can turn a motor without any position sensor and without any current measurement as the first step of doing the system setup. With the turning motor one can adjust the ADC scales and offsets and set up positions sensors (hall, incremental encoder, ...) according to resolution, orientation, direction of rotation.

3.6.2 Incremental ABN Encoder

The incremental encoders give two phase shifted incremental pulse signals A and B. Some incremental encoders have an additional null position signal N or zero pulse signal Z. An incremental encoder (called ABN encoder or ABZ encoder) has an individual number of incremental pulses per revolution. The number of incremental pulses define the number of positions per revolution (PPR). The PPR might mean pulses per revolution or periods per revolution. Instead of positions per revolution some incremental encoder vendors call these CPR counts per revolution.

The PPR parameter is the most important parameter of the incremental encoder interface. With that, it forms a modulo (PPR) counter, counting from 0 to (PPR-1). Depending on the direction, it counts up or



down. The modulo PPR counter is mapped into the register bank as a dual ported register. the user can over write it with an initial position. The ABN encoder interface provides both, the electrical position and the multi-turn position are dual-ported read-write registers.

Note

The PPR parameter must be set exactly according to the used encoder.

The N pulse from an encoder triggers either sampling of the actual encoder count to fetch the position at the N pulse or it re-writes the fetched n position on an N pulse. The N pulse can either be used as stand alone pulse or and-ed with NAB = N and A and B. It depends on the decoder what kind of N pulse has to be used, either N or NAB. For those encoders with precise N pulse within one AB quadrat, the N pulse must be used. For those encoders with N pulse over four AB quadrants one can enhance the precision of the N pulse position detection by using NAB instead of N.

Note

Incremental encoders are available with N pulse and without N pulse.




Figure 8: ABN Incremental Encoder N Pulse

The polarity of N pulse, A pulse and B pulse are programmable. The N pulse is for re-initialization with each turn of the motor. Once fetched, the ABN decoder can be configured to write back the fetched N pulse position with each N pulse.

Note

The ABN encoder interface has a direction bit to set once the direction of motion for the application.

Logical ABN = A and B and N might be useful for incremental encoders with low resolution N pulse to enhance the resolution. On the other hand, for incremental encoders with high resolution n pulse a logical abn = a and b and n might totally suppress the resulting n pulse.






Figure 9: Encoder ABN Timing - high precise *n* pulse and less precise *N* pulse

3.6.3 Secondary Incremental ABN Encoder

For commutating a motor with FOC one selects a position sensor source (digital incremental encoder, digital hall, analog hall, analog incremental encoder, ...) that is mounted close to the motor. The inner FOC loop control torque and flux of the motor based on the measured phase currents and the electrical angle of the rotor.

The TMC4670 is equipped with a secondary incremental encoders interface. This secondary encoder interface is available as source for velocity control or position control. This is for applications where a motor turns an object with a gear to position the object. An example is a robot arm where a motor moves an angle with a the mechanical angle of the arm as the target.


Info

The secondary incremental encoder is not available for commutation (ϕ_i_e) for the inner FOC. In others words, there is no electrical angle ϕ_i_e selectable from the secondary encoder.

3.6.4 Digital Hall Sensor Interface with optional Interim Position Interpolation

The digital hall interface is the position sensor interface for digital hall signals. The digital hall signal interface first maps the digital hall signals to an electrical position $\phi_i_e_{RAW}$. An offset $\phi_i_e_{OFFSET}$ can be used to rotated the orientation of the hall signal angle. The electrical angle ϕ_i_e is for commutation. Optionally, the default electrical positions of the Hall sensors can be adjusted by writes into the associated registers.





Hall Sensors give absolute positions within an electrical period with a resolution of 60° as 16 bit positions (s16 resp. u16) PHI. With activated interim hall position interpolation one additionally gets high resolution interim positions when the motor is running at speed beyond 60 rpm.

3.6.5 Digital Hall Sensor - Interim Position Interpolation

For lower torque ripple one can switch on the position interpolation of interim hall positions. This function is useful for motors that are compatible with sine wave commutation but equipped with digital hall sensors. When the position interpolation is switched on it becomes active on speed beyond 60 rpm. For lower speed it automatically disables. This is important especially when the motor has to be at rest. Motors that are intended for block commutation might smarter turn with hall signal interpolation but one should not expect too much for those motors.

3.6.6 Digital Hall together with Incremental Encoder

If a motor is equipped with both Hall sensors and incremental encoder, the hall sensors can be used for the initialization as a low resolution absolute position sensor and later the incremental encoder can be used as a high resolution sensor for commutation.



3.6.7 Analog Hall and Analog Encoder Interface (SinCos of 0°90° or 0°120°240°)

An analog encoder interface is part of the decoder engine. It is able to handle analog position signals of 0° and 90° and 0° 120° 240°. The analog decoder engine adds offset and scales the raw analog encoder signals and calculates the electrical angle PHI_E from these analog position signals.

ADC offsets and ADC scalers need to be programmed into the associated registers to use analog Hall sensors or analog encoders. Each AENC_0_SELECT, AENC_1_SELECT, AENC_2_SELECT, and AENC_3_SELECT, selects one raw analog ADC input channel AENC out of AENC_UX_RAW, AENC_VN_RAW, AENC_WY_RAW, AENC_N_RAW, or one AENC register channel AENC_UX_EXT, AENC_VN_EXT, AENC_WY_EXT, AENC_NEXT.

An individual signed offset is added each associated raw ADC channel and scaled by its associated scaling factors according to

$$\text{AENC_VALUE} = (\text{AENC_RAW} + \text{AENC_OFFSET}) \cdot \text{AENC_SCALE} \quad (5)$$

In addition, the AENC_OFFSET is for conversion of unsigned ADC values into signed ADC values as required for the FOC.




Figure 11: Analog Encoder (AENC) Selector & Scaler w/ Offset Correction



ⓘ Info

The analog N pulse is just a raw ADC value. Scaling, offset correction, hand handling of analog N pulse similar to N pulse handling of digital encoder N pulse is not implemented for analog encoder.

3.6.8 Analog Position Decoder (SinCos of 0°90° or 0°120°240°)

The extracted positions from the analog decoder are available for read out from registers.

3.6.8.1 Multi-Turn Counter

Electrical angles are mapped to a multi-turn position counter. The user can overwrite this multi-turn position for initialization purposes.

3.6.8.2 Encoder Engine Phi Selector

The angle selector select the source for the commutation angel PHI_E. That electrical angle is available for commutation.

3.6.8.3 External Position Register

A register value written via the application interface into the register bank is available for commutation also. With this, the user can interface to any encoder by just writing positions extracted from external encoder into this regulator. From the decoder engine point of view this is just one more selectable encoder source.

3.7 FOC23 Engine

 ⓘ Info

Support for the TMC4670 is integrated into the TMCL-IDE including wizards for setting up. With this one can turn a motor with a few steps of setup. with the TMCL-IDE one has direct access to all registers of the TMC4670.

The FOC23 engine performs the inner current control loop for the torque current I_Q and the flux current I_D including the required transformations. Programmable limiters take care of clipping of interim results. Per default, the programmable circular limiter clips U_D and U_Q to $U_{D_R} = \sqrt{2} \cdot U_Q$ and $U_{R_R} = \sqrt{2} \cdot U_D$. PI controllers perform the regulation tasks.

3.7.1 PI(D) Controllers

PI controllers are used for current control and velocity control. A P regulator is used for position control. The D part not yet supported, it is just a register place holder for future variants.



3.7.2 PI(D) Controller Calculations

The PI regulators performs the calculation

$$dXdT = P \cdot e + I \cdot \int_0^t e(t) dt \quad (6)$$

with

$$e = X_TARGET - X \quad (7)$$

where X_TARGET stands for target flux, target torque, target velocity, or target position with error e that is the difference between target value and actual values. The time constant dt is $1\mu s$ with the integral part is divided by 256.

3.7.3 PI(D) Controller - Clipping

The limiting of target values for PI controllers and output values of PI controllers is programmable. Per power on default theses limiter are set to maximum values. Before one starts a motor one should set the limiters for clipping.

The target input is clipped to X_TARGET_LIMIT . The output of a PI(D) is named $dXdT$ because it gives the desired derivative d/dt as a target value to the following stage: The position (x) controller gives velocity (dx/dt)

The output of the PI(D) is clipped to $dXdT_LIMIT$. The error integral of (6) is clipped to $dXdT_LIMIT / I$.






Figure 12: PID Architectures

3.7.4 PI Flux & PI Torque

The P part is represented as q8.8 and I is the I part represented as q0.15.

3.7.5 PI Velocity

The P part is represented as q8.8 and I is the I part represented as q0.15.



3.7.6 P(I) Position

For the position regulator, the P part is represented as q4.12 to be compatible with the high resolution positions - one single rotation is handled as an s16.

This is because $e = x - x_{target}$ might result in larger $e[s32]$ for $x[s32]$ and $x_{target}[s32]$ represented as s32 for $e = x - x_{target}$ for $x[s16]$ and $x_{target}[s16]$ represented as s16.

3.7.7 Inner FOC Control Loop - Flux & Torque

The inner FOC loop (figure 13) regulates the flux current to a flux target of zero and the torque current to the desired torque target. The inner FOC loop performs the desired transformations according to figure 14 for 3-phase motors (FOC3). For 2-phase motors (FOC2) both Clark (CLARK) transformation and inverse Clark (iCLARK) a by-passed.

The inner FOC control loop gets a target torque value (I_{Q_TARGET}) that represents acceleration, the rotor position, and the measured currents as input data. Together with the programmed P and I parameters, the inner FOC loop calculates three target voltage values as input for the PWM engine.




Figure 13: Inner FOC Control Loop

3.7.8 FOC Transformations and PI(D) for control of Flux & Torque

The Clark transformation (CLARKE) maps three motor phase currents (I_U, I_V, I_W) to a two dimensional coordinate system with two currents (I_α, I_β). Based on the actual rotor angle determined by an encoder or via sensorless techniques, the Park transformation (PARK) maps these two currents to a quasi-static coordinate system with two currents (I, I_Q). The current I represents flux and the current I_Q represents torque. The flux just pulls on the rotor but does not effect torque. The torque is effected by the (I_Q). Two PI controllers determine two voltages (U_D, U_Q) to drive desired currents for a target torque and a target flux of zero. The determined voltages (U_D, U_Q) are re-transformed into the stator system by the inverse Parke transformation (iPARK). The inverse Clarke Transformation (iCLARKE) transform these two currents into three voltages (U_U, U_V, U_W). Theses three voltage are the input of the PWM engine to drive the power stage.

In case of the FOC2, Clarke transformation CLARKE and inverse Clarke Transformation iCLARKE are skipped.






Figure 14: FOC3 Transformations (FOC2 just skips CLARKE and iCLARKE)

3.7.9 Motion Modes




Figure 15: Motion Modes

3.8 PWM Engine

The PWM engine takes care converting voltage vectors to pulse width modulated (PWM) control signals. These digital PWM signals control the gate drivers of the power stage. For detailed description of the PWM control registers and PWM register control bits pls. refer section 5 page 27.

The ease-of-use PWM Engine requires just a couple of parameter settings. Primarily, the polarities for the gate control signal of high side and low side must be set. The power on default PWM mode is 0 that



means PWM = OFF. For operation, the centered PWM mode must be set on by setting the PWM mode to 7. A single bit controls the Space vector PWM (SVPWM). For 3-phase PMSM the SVPWM = ON gives more effective voltage. Nevertheless, for some applications it makes sense to switch the SVPWM = OFF to keep the star point voltage of a motor almost at rest.

3.8.1 PWM Polarities

This PWM polarities register PWM_POLARITES controls the polarities of the control signals. Positive polarity for gate control means 1 represents ON and 0 represents OFF. The gate control signal polarities are individually programmable for low side gate control and for high side gate control. The PWM polarities register controls the polarity of other control signals as well.

3.8.2 PWM frequency

The PWM counter maximum length register PWM_MAXCNT controls the PWM frequency. For a clock frequency fCLK = 25MHz, the PWM frequency fPWM[Hz] = $(4.0 * fCLK[\text{Hz}]) / (\text{PWM_MAXCNT} + 1)$. With fCLK = 25MHz and power-on reset (POR) default of PWM_MAXCNT=3999 the PWM frequency is fPWM = 25kHz. The PWM frequency fPWM is recommended to be in the range of 25kHz to 200kHz by setting PWM_MAXCNT between 3999 to 499.

Note

The PWM frequency can be changed any time also during motion.

3.8.3 PWM Resolution

The base resolution of the PWM is 12 bit internally mapped to 16 bit range. MAX_PWM_CNT=4095 gives the full resolution of 12 bit with $\approx 25\text{kHz}$ w/ fCLK=25MHz. MAX_PWM_CNT=2047 results in 11 bit resolution but with $\approx 50\text{kHz}$ w/ fCLK=25MHz. So the PWM_MAXCNT defines the PWM frequency but effects the resolution of the PWM.

3.8.4 PWM Modes

The power-on reset (POR) default of the PWM is OFF. The standard PWM scheme is the centered PWM. Passive Breaking and Free Wheeling Modes are available on demand. Please refer [?] concerning the settings.

3.8.5 Brake-Before-Make (BBM)

One register controls BBM time for the high side. One register controls BBM time for the low side. The BBM times are programmable in 10ns steps. The BBM time can be set to zero for gate drivers that have their own integrated BBM timers.






Figure 16: BBM Timing

Info

Measured BBM times at MOS-FET gates differs from programmed BBM times due to driver delays and possible additional gate driver BBM times. The programmed BBM times are for the digital control signals.

Note

Too small BBM times cause electrical short of the MOS-FET bridges - so called shoot through - that shorts the power supply and might damage the power stage and the power supply.

3.8.6 Space Vector PWM (SVPWM)

A single bit controls the internal Space vector PWM (SVPWM) enable. No further setting are required for the space vector PWM - just ON or OFF. The power on default for the SVPWM is OFF.

Note

The SVPWM is for 3-phase motors only. For 2-phase motors there is no SVPWM.

4 Safety Functions

Different safety functions are integrated and mapped to status bits. Two programmable mask register select those bits for WARNING or ERROR. Warning just indicated the warning status at the WARNING output. An Error will cause programmable actions on error conditions and indicate the error status directly at ERROR output, as PWM = OFF on over current condition or ADC raw values with permanent zero or ADC raw values at maximum, ...

Info

Programmable autonomous error handling is not implemented yet.

Internal hardware limiters for real time clipping and monitoring of interim values are available. LIMIT or LIMITS is part of register names of registers associated to internal limiters. Please refer 5.



5 Register Map

Info

This is a preliminary register map. Address mappings and register mappings might change for the release version. Names of some register addresses and names of register part might be changed for the release version.

Register Map for TMC4670				
Address	Registername			Access
0x00h	CHIPINFO_DATA			R
	Variant 0			
	Mask	Name		Type
	0xFFFFFFFFh	SI_TYPE		ASCII
	Min	Max	Default	Unit
	0	4294967295	0	
	Hardware type (ASCII).			
	Variant 1			
	Mask	Name		Type
	0xFFFFFFFFh	SI_VERSION		Version
	Min	Max	Default	Unit
	0	4294967295	0	
	Hardware version (u16.u16).			
	Variant 2			
	Mask	Name		Type
	0xFFFFFFFFh	SI_DATE		Date
	Min	Max	Default	Unit
	0	4294967295	0	
	Hardware date (nibble wise date stamp yyyyymmdd).			
	Variant 3			
	Mask	Name		Type
	0xFFFFFFFFh	SI_TIME		Time
	Min	Max	Default	Unit
	0	16777215	0	
	Hardware time (nibble wise time stamp -hhmmss)			
	Variant 4			
	Mask	Name		Type
	0xFFFFFFFFh	SI_VARIANT		Unsigned

Address	Registername					Access	
		Min	Max	Default	Unit		
0x01 _h	CHIPINFO_ADDR					RW	
0x01 _h	Mask	Name			Type		
	0x000000FF _h	CHIP_INFO_ADDRESS			Choice		
		Min	Max	Default	Unit		
		0	4	0			
	0: SI_TYPE						
	1: SI_VERSION						
	2: SI_DATE						
	3: SI_TIME						
	4: SI_VARIANT						
	ADC_RAW_DATA						
0x02 _h	Variant 0					R	
	Mask	Name			Type		
	0x0000FFFF _h	ADC_I_UX_RAW			Unsigned		
		Min	Max	Default	Unit		
		0	65535	0			
	Raw phase current U resp. X (LTC2351).						
	Mask	Name			Type		
	0xFFFF0000 _h	ADC_I_WY_RAW			Unsigned		
		Min	Max	Default	Unit		
		0	65535	0			
	Raw phase current W resp. Y (LTC2351).						
0x02 _h	Variant 1						
	Mask	Name			Type		
	0x0000FFFF _h	ADC_I_U_RAW			Unsigned		
		Min	Max	Default	Unit		
		0	65535	0			
	Raw phase current U (ADC_I_UX analog input for FOC2).						
	Mask	Name			Type		
	0xFFFF0000 _h	ADC_I_V_RAW			Unsigned		
		Min	Max	Default	Unit		
		0	65535	0			
	Raw phase current V (ADC_I_WY analog input for FOC2).						

Address	Registername				Access
	Variant 2				
Mask	Name			Type	
0x0000FFFF _h	ADC_I_B_RAW			Unsigned	
	Min	Max	Default	Unit	
	0	65535	0		
Raw phase current Bottom (analog input).					
	Variant 3				
Mask	Name			Type	
0x0000FFFF _h	ADC_VM_RAW			Unsigned	
	Min	Max	Default	Unit	
	0	65535	0		
Raw supply voltage.					
	Variant 4				
Mask	Name			Type	
0x0000FFFF _h	ADC_T_MOSFETS_RAW			Unsigned	
	Min	Max	Default	Unit	
	0	65535	0		
Raw mosfet temperature.					
Mask	Name			Type	
0xFFFF0000 _h	ADC_T_MOTOR_RAW			Unsigned	
	Min	Max	Default	Unit	
	0	65535	0		
Raw motor temperature.					
	Variant 5				
Mask	Name			Type	
0x0000FFFF _h	ADC_U_UX_RAW			Unsigned	
	Min	Max	Default	Unit	
	0	65535	0		
Raw voltage terminal U resp. X.					
Mask	Name			Type	
0xFFFF0000 _h	ADC_U_WY_RAW			Unsigned	
	Min	Max	Default	Unit	
	0	65535	0		
Raw voltage terminal W resp. Y.					
	Variant 6				



Address	Registername				Access
	Mask	Name			Type
	0x0000FFFF _h	ADC_U_V_RAW			Unsigned
		Min	Max	Default	Unit
		0	65535	0	
	Raw voltage terminal V.				
	Variant 7				
	Mask	Name			Type
	0x0000FFFF _h	AENC_UX_RAW			Unsigned
		Min	Max	Default	Unit
		0	65535	0	
	Raw analog encoder voltage U resp. X.				
	Mask	Name			Type
	0xFFFF0000 _h	AENC_WY_RAW			Unsigned
		Min	Max	Default	Unit
		0	65535	0	
	Raw analog encoder voltage W resp. Y.				
	Variant 8				
	Mask	Name			Type
	0x0000FFFF _h	AENC_V_RAW			Unsigned
		Min	Max	Default	Unit
		0	65535	0	
	Raw analog encoder voltage V.				
	Mask	Name			Type
	0xFFFF0000 _h	AENC_N_RAW			Unsigned
		Min	Max	Default	Unit
		0	65535	0	
	Raw analog encoder zero position voltage N.				
	Variant 9				
	Mask	Name			Type
	0x0000FFFF _h	ANALOG_GPI_RAW			Unsigned
		Min	Max	Default	Unit
		0	65535	0	
	Raw analog input voltage.				
	Variant 10				
	Mask	Name			Type



Address	Registername				Access	
0x0000FFFFh	ADCSD_I_UX_RAW	Signed				
	Min	Max	Default	Unit		
	-32768	32767	0			
	SigmaDeltaADC current UX.					
	Mask	Name		Type		
	0xFFFF0000h	ADCSD_I_WY_RAW		Signed		
	Min	Max	Default	Unit		
	-32768	32767	0			
	SigmaDeltaADC current WY.					
	Variant 11					
0x0000FFFFh	Mask	Name		Type		
	ADCSD_I_B_RAW	Signed				
	Min	Max	Default	Unit		
	-32768	32767	0			
SigmaDeltaADC current at bottom (PCB S (sense) instead of B (bottom)).						
0x03h	ADC_RAW_ADDR				RW	
	Mask	Name		Type		
	0x000000FFh	ADC_RAW_ADDR		Choice		
	Min	Max	Default	Unit		
	0	11	0			
	0: ADC_I_WY_RAW & ADC_I_UX_RAW					
	1: ADC_I_V_RAW & ADC_I_U_RAW					
	2: ADC_I_B_RAW					
	3: ADC_VM_RAW					
	4: ADC_T_MOSFETS_RAW & ADC_T_MOTOR_RAW					
	5: ADC_U_WY_RAW & ADC_U_UX_RAW					
	6: ADC_U_V_RAW					
0x04h	7: AENC_WY_RAW & AENC_UX_RAW					
	8: AENC_N_RAW & AENC_V_RAW					
	9: ANALOG_GPI_RAW					
	10: ADCSD_I_WY_RAW & ADCSD_I_UX_RAW					
	11: ADCSD_I_B_RAW					
	Mask	Name		Type		



Address	Registername				Access
	0x0000FFFFh	ADCSD_CLKCFG	Unsigned		
		Min	Max	Default	Unit
		0	65535	0	
0x06h	ADC_I1_IO_EXT				RW
	Mask	Name		Type	
	0x0000FFFFh	ADC_IO_EXT		Unsigned	
		Min	Max	Default	Unit
		0	65535	0	
	Register for write of ADC_I0 value from external source (eg. CPU).				
	Mask	Name		Type	
	0xFFFF0000h	ADC_I1_EXT		Unsigned	
		Min	Max	Default	Unit
		0	65535	0	
	Register for write of ADC_I1 value from external source (eg. CPU).				
0x08h	ADC_I1_SCALE_OFFSET				RW
	Mask	Name		Type	
	0x0000FFFFh	ADC_I1_OFFSET		Signed	
		Min	Max	Default	Unit
		-32768	32767	0	
	Offset for current ADC channel 1.				
	Mask	Name		Type	
	0xFFFF0000h	ADC_I1_SCALE		Signed	
		Min	Max	Default	Unit
		-32768	32767	0	
	Scaling factor for current ADC channel 1.				
0x09h	ADC_I0_SCALE_OFFSET				RW
	Mask	Name		Type	
	0x0000FFFFh	ADC_I0_OFFSET		Signed	
		Min	Max	Default	Unit
		-32768	32767	0	
	Offset for current ADC channel 0.				
	Mask	Name		Type	
	0xFFFF0000h	ADC_I0_SCALE		Signed	



Address	Registername					Access
		Min	Max	Default	Unit	
	Scaling factor for current ADC channel 0.					
0x0Ah	ADC_I_SELECT					RW
	Mask	Name			Type	
	0x000000FFh	ADC_I0_SELECT			Choice	
	Min	Max	Default	Unit		
	0	7	0			
	Select input for raw current ADC_I0_RAW.					
	0: ADC_I0_RAW (analog input ADC_I_U) 1: ADC_I1_RAW (analog input ADC_I_V) 2: ADC_I0_EXT (from register) 3: ADC_I1_EXT (from register) 4: ADCSD_I0_RAW (sigma delta ADC) 5: ADCSD_I1_RAW (sigma delta ADC) 6: ADCSPI_I0_RAW (SPI ADC_I_UX) 7: ADCSPI_I1_RAW (SPI ADC_I_WY)					
	Mask	Name			Type	
	0x0000FF00h	ADC_I1_SELECT			Choice	
	Min	Max	Default	Unit		
	0	7	0			
	Select input for raw current ADC_I1_RAW.					
	0: ADC_I0_RAW (analog input ADC_I_U) 1: ADC_I1_RAW (analog input ADC_I_V) 2: ADC_I0_EXT (from register) 3: ADC_I1_EXT (from register) 4: ADCSD_I0_RAW (sigma delta ADC) 5: ADCSD_I1_RAW (sigma delta ADC) 6: ADCSPI_I0_RAW (SPI ADC_I_UX) 7: ADCSPI_I1_RAW (SPI ADC_I_WY)					
	Mask	Name			Type	
	0x03000000h	ADC_I_UX_SELECT			Choice	
	Min	Max	Default	Unit		
	0	2	0			
	0: UX = ADC_I0 (default)					



Address	Registername				Access	
0x0C000000h	1: UX = ADC_I1 2: UX = ADC_I2					
	Mask	Name				
	0x0C000000h	ADC_I_V_SELECT				
		Min	Max	Default		
		0	2	0		
	0: V = ADC_I0 1: V = ADC_I1 (default) 2: V = ADC_I2					
	Mask	Name				
	0x30000000h	ADC_I_WY_SELECT				
		Min	Max	Default		
		0	2	0		
	0: WY = ADC_I0 1: WY = ADC_I1 2: WY = ADC_I2 (default)					
0x0Dh	AENC_0_SCALE_OFFSET				RW	
	Mask	Name				
	0x0000FFFFh	AENC_0_OFFSET				
		Min	Max	Default		
		-32768	32767	0		
	Offset for Analog Encoder ADC channel 0.					
	Mask	Name				
	0xFFFF0000h	AENC_0_SCALE				
		Min	Max	Default		
		-32768	32767	0		
	Scaling factor for Analog Encoder ADC channel 0.					
0x0Eh	AENC_1_SCALE_OFFSET				RW	
	Mask	Name				
	0x0000FFFFh	AENC_1_OFFSET				
		Min	Max	Default		
		-32768	32767	0		
	Offset for Analog Encoder ADC channel 1.					
0xFFFF0000h	Mask	Name			Signed	
	0xFFFF0000h	AENC_1_SCALE			Signed	



Address	Registername					Access	
		Min	Max	Default	Unit		
		-32768	32767	0			
Scaling factor for Analog Encoder ADC channel 1.							
0x0Fh	AENC_2_SCALE_OFFSET					RW	
	Mask	Name			Type		
	0x0000FFFFh	AENC_2_OFFSET			Signed		
	Min	Max	Default	Unit			
	-32768	32767	0				
	Offset for Analog Encoder ADC channel 2.						
	Mask	Name			Type		
0x10h	0xFFFF0000h	AENC_2_SCALE			Signed	RW	
	Min	Max	Default	Unit			
	-32768	32767	0				
	Scaling factor for Analog Encoder ADC channel 2.						
	Mask	Name			Type		
	0x0000FFFFh	AENC_3_OFFSET			Signed		
	Min	Max	Default	Unit			
0x11h	-32768	32767	0			RW	
	Offset for Analog Encoder ADC channel 3.						
	Mask	Name			Type		
	0xFFFF0000h	AENC_3_SCALE			Signed		
	Min	Max	Default	Unit			
	-32768	32767	0				
	Scaling factor for Analog Encoder ADC channel 3.						
AENC_SELECT							
0x11h	Mask	Name			Type	RW	
	0x000000FFh	AENC_0_SELECT			Choice		
	Min	Max	Default	Unit			
	0	3	0				
	Select analog encoder ADC channel for raw analog encoder signal AENC_0_RAW.						
	0: AENC_UX_RAW (default)						
	1: AENC_VN_RAW						
2: AENC_WY_RAW							



Address	Registername				Access
	3: AENC_N_RAW				
Mask	Name			Type	
0x0000FF00h	AENC_1_SELECT			Choice	
	Min	Max	Default	Unit	
	0	3	0		
	Select analog encoder ADC channel for raw analog encoder signal AENC_1_RAW.				
	0: AENC_UX_RAW				
	1: AENC_VN_RAW (default)				
	2: AENC_WY_RAW				
	3: AENC_N_RAW				
Mask	Name			Type	
0x00FF0000h	AENC_2_SELECT			Choice	
	Min	Max	Default	Unit	
	0	3	0		
	Select analog encoder ADC channel for raw analog encoder signal AENC_2_RAW.				
	0: AENC_UX_RAW				
	1: AENC_VN_RAW				
	2: AENC_WY_RAW (default)				
	3: AENC_N_RAW				
Mask	Name			Type	
0xFF000000h	AENC_3_SELECT			Choice	
	Min	Max	Default	Unit	
	0	3	0		
	Select analog encoder ADC channel for raw analog encoder signal AENC_3_RAW.				
	0: AENC_UX_RAW				
	1: AENC_VN_RAW				
	2: AENC_WY_RAW				
	3: AENC_N_RAW (default)				
0x12h	ADC_IWY_IUX				R
Mask	Name			Type	
0x0000FFFFh	ADC_IUX			Signed	
	Min	Max	Default	Unit	
	-32768	32767	0		



Address	Registername				Access
	Register of scaled current ADC value including signed added offset as input for the FOC.				
Mask	Name			Type	
0xFFFF0000 _h	ADC_IWY			Signed	
	Min	Max	Default	Unit	
	-32768	32767	0		
	Register of scaled current ADC value including signed added offset as input for the FOC.				
0x13 _h	ADC_IV				R
Mask	Name			Type	
0x0000FFFF _h	ADC_IV			Signed	
	Min	Max	Default	Unit	
	-32768	32767	0		
	Register of scaled current ADC value including signed added offset as input for the FOC.				
0x15 _h	AENC_WY_UX				R
Mask	Name			Type	
0x0000FFFF _h	AENC_UX			Signed	
	Min	Max	Default	Unit	
	-32768	32767	0		
	Register of scaled analog encoder value including signed added offset as input for the interpolator.				
Mask	Name			Type	
0xFFFF0000 _h	AENC_WY			Signed	
	Min	Max	Default	Unit	
	-32768	32767	0		
	Register of scaled analog encoder value including signed added offset as input for the interpolator.				
0x16 _h	AENC_N_VN				R
Mask	Name			Type	
0x0000FFFF _h	AENC_VN			Signed	
	Min	Max	Default	Unit	
	-32768	32767	0		
	Register of scaled analog encoder value including signed added offset as input for the interpolator.				
Mask	Name			Type	
0xFFFF0000 _h	AENC_N			Signed	



Address	Registername					Access
		Min	Max	Default	Unit	
	-32768	32767	0			
	Register of scaled analog encoder value including signed added offset of analog N pulse.					
0x17 _h	PWM_POLARITIES					RW
	Mask	Name			Type	
	0x00000001 _h	PWM_POLARITIES[0]			Bool	
		Min	Max	Default	Unit	
		0	1	0		
	polarity of Low Side (LS) gate control signal					
	0: off					
	1: on					
	Mask	Name			Type	
	0x00000002 _h	PWM_POLARITIES[1]			Bool	
		Min	Max	Default	Unit	
		0	1	0		
	polarity of High Side (HS) gate control signal					
	0: off					
	1: on					
	Mask	Name			Type	
	0x00000004 _h	PWM_POLARITIES[2]			Bool	
		Min	Max	Default	Unit	
		0	1	0		
	pulse AB polarity					
	0: off					
	1: on					
	Mask	Name			Type	
	0x00000008 _h	PWM_POLARITIES[3]			Bool	
		Min	Max	Default	Unit	
		0	1	0		
	pulse B polarity					
	0: off					
	1: on					
	Mask	Name			Type	
	0x00000010 _h	PWM_POLARITIES[4]			Bool	



Address	Registername					Access
		Min	Max	Default	Unit	
		0	1	0		
pulse C center polarity 0: off 1: on						
Mask	Name			Type		
0x00000020 _h	PWM_POLARITIES[5]			Bool		
	Min	Max	Default	Unit		
	0	1	0			
pulse A polarity 0: off 1: on						
Mask	Name			Type		
0x00000040 _h	PWM_POLARITIES[6]			Bool		
	Min	Max	Default	Unit		
	0	1	0			
pulse zero Z pulse polarity 0: off 1: on						
Mask	Name			Type		
0x00000080 _h	PWM_POLARITIES[7]			Bool		
	Min	Max	Default	Unit		
	0	1	0			
over current signal polarity 0: off 1: on						
0x18 _h	PWM_MAXCNT					RW
Mask	Name			Type		
0x0000FFFF _h	PWM_MAXCNT			Unsigned		
	Min	Max	Default	Unit		
	0	65535	0			
PWM maximum (count-1), PWM frequency is fPWM[Hz] = 100MHz/(PWM_MAXCNT+1)						
0x19 _h	PWM_BBM_H_BBM_L					RW
Mask	Name			Type		

Address	Registername				Access
	0x000000FF _h	PWM_BBM_L	Unsigned		
		Min	Max	Default	Unit
		0	255	0	
	Break Before Make time tBBM_L[10ns] for low side MOS-FET gate control				
	Mask	Name			Type
	0x0000FF00 _h	PWM_BBM_H			Unsigned
		Min	Max	Default	Unit
		0	255	0	
	Break Before Make time tBBM_H[10ns] for high side MOS-FET gate control				
0x1A _h	PWM_SV_CHOP				RW
	Mask	Name			Type
	0x000000FF _h	PWM_CHOP			Choice
		Min	Max	Default	Unit
		0	7	0	
	PWM chopper mode, defining how to chopper				
	0: PWM = OFF, free running				
	1: PWM = OFF, Low Side (LS) permanent = ON				
	2: PWM = OFF, High Side (HS) permanent = ON				
	3: PWM off, free running				
	4: PWM off, free running				
	5: PWM low side (LS) chopper only, high side (HS) off; not suitable for FOC				
	6: PWM high side (HS) chopper only, low side (LS) off; not suitable for FOC				
	7: centered PWM for FOC				
	Mask	Name			Type
	0x00000100 _h	PWM_SV			Bool
		Min	Max	Default	Unit
		0	1	0	
	use Space Vector PWM				
	0: Space Vector PWM disabled				
	1: Space Vector PWM enabled				
0x1B _h	MOTOR_TYPE_N_POLE_PAIRS				RW
	Mask	Name			Type



Address	Registername				Access
0x0000FFFFh	N_POLE_PAIRS	Min	Max	Default	Unsigned Unit
	1	65535	1		
	Number n of pole pairs of the motor for calcualtion $\phi_e = \phi_m / N_POLE_PAIRS$.				
Mask	Name			Type	
	MOTOR_TYPE			Choice	
	Min	Max	Default	Unit	
	0	3	0		
0: FOC2 1: FOC3 2: reserved 3: reserved					
0x1Ch	PHI_E_EXT				RW
Mask	Name			Type	
	PHI_E_EXT			Signed	
	Min	Max	Default	Unit	
	-32768	32767	0		
Electrical angle phi_e_ext for external writing into this register.					
0x1Dh	PHI_M_EXT				RW
Mask	Name			Type	
	PHI_M_EXT			Signed	
	Min	Max	Default	Unit	
	-32768	32767	0		
Mechanical angle phi_m_ext for external writing into this register.					
0x1Eh	POSITION_EXT				RW
Mask	Name			Type	
	POSITION_EXT			Signed	
	Min	Max	Default	Unit	
	-2147483648	2147483647	0		
Mechanical (multi turn) position for external writing into this register.					
0x1Fh	OPENLOOP_MODE				RW
Mask	Name			Type	
	OPENLOOP_PHI_DIRECTION			Bool	



Address	Registername					Access
		Min	Max	Default	Unit	
		0	1	0		
Open loop phi direction. 0: positive 1: negative						
0x20 _h	OPENLOOP_ACCELERATION					RW
	Mask	Name			Type	
	0xFFFFFFFF _h	OPENLOOP_ACCELERATION			Unsigned	
	Min	Max	Default	Unit		
	0	4294967295	0			
Acceleration of open loop phi.						
0x21 _h	OPENLOOP_VELOCITY_TARGET					RW
	Mask	Name			Type	
	0xFFFFFFFF _h	OPENLOOP_VELOCITY_TARGET			Signed	
	Min	Max	Default	Unit		
	-2147483648	2147483647	0			
Target velocity of open loop phi.						
0x22 _h	OPENLOOP_VELOCITY_ACTUAL					RW
	Mask	Name			Type	
	0xFFFFFFFF _h	OPENLOOP_VELOCITY_ACTUAL			Signed	
	Min	Max	Default	Unit		
	-2147483648	2147483647	0			
Actual velocity of open loop generator.						
0x23 _h	OPENLOOP_PHI					RW
	Mask	Name			Type	
	0x0000FFFF _h	OPENLOOP_PHI			Signed	
	Min	Max	Default	Unit		
	-32768	32767	0			
Angle phi open loop (either mapped to electrical angel phi_e or mechanical angle phi_m).						
0x24 _h	UQ_UD_EXT					RW
	Mask	Name			Type	
	0x0000FFFF _h	UD_EXT			Signed	
	Min	Max	Default	Unit		
	-32768	32767	0			



Address	Registername				Access	
	Mask	Name		Type		
0xFFFF0000 _h	0xFFFF0000 _h	External writable parameter for open loop voltage control mode, usefull during system setup, U_D component.				
		UQ_EXT		Signed		
		Min	Max	Default		
	-32768	32767	0			
External writable parameter for open loop voltage control mode, usefull during system setup, U_Q component.						
0x25 _h	ABN_DECODER_MODE				RW	
	Mask	Name		Type		
	0x00000001 _h	apol				
		Min	Max	Default		
		0	1	0		
	Polarity of A pulse. 0: off 1: on					
	Mask	Name		Type		
	0x00000002 _h	bpol				
		Min	Max	Default		
		0	1	0		
	Polarity of B pulse. 0: off 1: on					
	Mask	Name		Type		
	0x00000004 _h	npol				
		Min	Max	Default		
		0	1	0		
	Polarity of N pulse. 0: off 1: on					
	Mask	Name		Type		
	0x00000008 _h	use_abn_as_n				
		Min	Max	Default		
		0	1	0		
	0: Ignore A and B polarity with Npulse = N, 1 : Npulse = N and A and B					

Address	Registername				Access
	0: Ignore A and B polarity with Npulse = N 1: Npulse = N and A and B				
	Mask	Name		Type	
	0x00000100h	cln		Bool	
		Min	Max	Default	Unit
		0	1	0	
	Clear writes ABN_DECODER_COUNT_N into decoder count at Npulse. 0: off 1: on				
	Mask	Name		Type	
	0x00001000h	direction		Bool	
		Min	Max	Default	Unit
		0	1	0	
	Decoder count direction. 0: positive 1: negative				
0x26h	ABN_DECODER_PPR				RW
	Mask	Name		Type	
	0x00FFFFFFh	ABN_DECODER_PPR		Unsigned	
		Min	Max	Default	Unit
		0	16777215	0	
	Decoder pules per mechanical revolution.				
0x27h	ABN_DECODER_COUNT				RW
	Mask	Name		Type	
	0x00FFFFFFh	ABN_DECODER_COUNT		Unsigned	
		Min	Max	Default	Unit
		0	16777215	0	
	Raw decoder count; the digital decoder engine counts modulo (decoder_ppr).				
0x28h	ABN_DECODER_COUNT_N				RW
	Mask	Name		Type	
	0x00FFFFFFh	ABN_DECODER_COUNT_N		Unsigned	
		Min	Max	Default	Unit
		0	16777215	0	



Address	Registername				Access	
		Decoder count latched on N pulse, when N pulse clears decoder_count also decoder_count_n is 0.				
0x29h	ABN_DECODER_PHI_E_PHI_M_OFFSET				RW	
	Mask	Name		Type		
	0x0000FFFFh	ABN_DECODER_PHI_M_OFFSET		Signed		
	Min	Max	Default	Unit		
	-32768	32767	0			
	ABN_DECODER_PHI_M_OFFSET to shift (rotate) angle DECODER_PHI_M.					
	Mask	Name		Type		
	0xFFFF0000h	ABN_DECODER_PHI_E_OFFSET		Signed		
	Min	Max	Default	Unit		
	-32768	32767	0			
	ABN_DECODER_PHI_E_OFFSET to shift (rotate) angle DECODER_PHI_E.					
0x2Ah	ABN_DECODER_PHI_E_PHI_M				R	
	Mask	Name		Type		
	0x0000FFFFh	ABN_DECODER_PHI_M		Signed		
	Min	Max	Default	Unit		
	-32768	32767	0			
	ABN_DECODER_PHI_M = ABN_DECODER_COUNT * 2 ¹⁶ / ABN_DECODER_PPR + ABN_DECODER_PHI_M_OFFSET;					
	Mask	Name		Type		
	0xFFFF0000h	ABN_DECODER_PHI_E		Signed		
	Min	Max	Default	Unit		
	-32768	32767	0			
	ABN_DECODER_PHI_E = (ABN_DECODER_PHI_M * N_POLE_PAIRS_) + ABN_DECODER_PHI_E_OFFSET					
0x2Ch	ABN_2_DECODER_MODE				RW	
	Mask	Name		Type		
	0x00000001h	apol		Bool		
	Min	Max	Default	Unit		
	0	1	0			
Polarity of A pulse. 0: off 1: on						



Address	Registername				Access
	Mask	Name		Type	
	0x00000002 _h	bpol		Bool	
		Min	Max	Default	Unit
		0	1	0	
	Polarity of B pulse. 0: off 1: on				
	Mask	Name		Type	
	0x00000004 _h	npol		Bool	
		Min	Max	Default	Unit
		0	1	0	
	Polarity of N pulse. 0: off 1: on				
	Mask	Name		Type	
	0x00000008 _h	use_abn_as_n		Bool	
		Min	Max	Default	Unit
		0	1	0	
	0: Ignore A and B polarity with Npulse = N, 1 : Npulse = N and A and B 0: Ignore A and B polarity with Npulse = N 1: Npulse = N and A and B				
	Mask	Name		Type	
	0x00000100 _h	cln		Bool	
		Min	Max	Default	Unit
		0	1	0	
	Clear writes ABN_2_DECODER_COUNT_N into decoder count at Npulse. 0: off 1: on				
	Mask	Name		Type	
	0x00001000 _h	direction		Bool	
		Min	Max	Default	Unit
		0	1	0	
	Decoder count direction. 0: positive				



Address	Registername				Access	
	1: negative					
0x2D _h	ABN_2_DECODER_PPR				RW	
	Mask	Name				
	0x00FFFFFF _h	ABN_2_DECODER_PPR				
	Min	Max	Default	Type		
	1	16777215	0	Unsigned		
Decoder_2 pules per mechanical revolution. This 2nd ABN encoder interface is for positioning or velocity control but NOT for motor commutation.						
0x2E _h	ABN_2_DECODER_COUNT				RW	
	Mask	Name				
	0x00FFFFFF _h	ABN_2_DECODER_COUNT				
	Min	Max	Default	Type		
	0	16777215	0	Unsigned		
Raw decoder_2 count; the digital decoder engine counts modulo (decoder_2_ppr).						
0x2F _h	ABN_2_DECODER_COUNT_N				RW	
	Mask	Name				
	0x00FFFFFF _h	ABN_2_DECODER_COUNT_N				
	Min	Max	Default	Type		
	0	16777215	0	Unsigned		
Decoder_2 count latched on N pulse, when N pulse clears decoder_2_count also decoder_2_count_n is 0.						
0x30 _h	ABN_2_DECODER_PHI_M_OFFSET				RW	
	Mask	Name				
	0x0000FFFF _h	ABN_2_DECODER_PHI_M_OFFSET				
	Min	Max	Default	Type		
	-32768	32767	0	Signed		
ABN_2_DECODER_PHI_M_OFFSET to shift (rotate) angle DECODER_2_PHI_M.						
0x31 _h	ABN_2_DECODER_PHI_M				R	
	Mask	Name				
	0x0000FFFF _h	ABN_2_DECODER_PHI_M				
	Min	Max	Default	Type		
	-32768	32767	0	Signed		



Address	Registername				Access
	ABN_2_DECODER_PHI_M = ABN_2_DECODER_COUNT * 2 ¹⁶ / ABN_2_DECODER_PPR + ABN_2_DECODER_PHI_M_OFFSET;				
0x33 _h	HALL_MODE				RW
	Mask	Name		Type	
	0x00000001 _h	polarity		Bool	
		Min	Max	Default	Unit
		0	1	0	
	polarity 0: off 1: on				
	Mask	Name		Type	
	0x00000100 _h	interpolation		Bool	
		Min	Max	Default	Unit
		0	1	0	
	interpolation 0: off 1: on				
	Mask	Name		Type	
	0x00001000 _h	direction		Bool	
		Min	Max	Default	Unit
		0	1	0	
	direction 0: off 1: on				
0x34 _h	HALL_POSITION_060_000				RW
	Mask	Name		Type	
	0x0000FFFF _h	HALL_POSITION_000		Signed	
		Min	Max	Default	Unit
		-32768	32767	0	
	s16 hall sensor position at 0°				
	Mask	Name		Type	
	0xFFFF0000 _h	HALL_POSITION_060		Signed	
		Min	Max	Default	Unit
		-32768	32767	0	
	s16 hall sensor position at 60°.				

Address	Registername				Access	
0x35h	HALL_POSITION_180_120				RW	
	Mask	Name				
	0x0000FFFFh	HALL_POSITION_120				
	Min	Max	Default	Type		
	-32768	32767	0	Signed		
	s16 hall sensor position at 120°.					
	Mask	Name				
	0xFFFF0000h	HALL_POSITION_180				
	Min	Max	Default	Type		
	-32768	32767	0	Signed		
s16 hall sensor position at 180°.						
0x36h	HALL_POSITION_300_240				RW	
	Mask	Name				
	0x0000FFFFh	HALL_POSITION_240				
	Min	Max	Default	Type		
	-32768	32767	0	Signed		
	s16 hall sensor position at 240°.					
	Mask	Name				
	0xFFFF0000h	HALL_POSITION_300				
	Min	Max	Default	Type		
	-32768	32767	0	Signed		
s16 hall sensor position at 300°.						
0x37h	HALL_PHI_E_PHI_M_OFFSET				RW	
	Mask	Name				
	0x0000FFFFh	HALL_PHI_M_OFFSET				
	Min	Max	Default	Type		
	-32768	32767	0	Signed		
	Offset of mechanical angle hall_phi_m of hall decoder.					
	Mask	Name				
	0xFFFF0000h	HALL_PHI_E_OFFSET				
	Min	Max	Default	Type		
	-32768	32767	0	Signed		
Offset for electrical angle hall_phi_e of hall decoder.						
0x38h	HALL_DPHI_MAX				RW	
	Mask	Name			Type	



Address	Registername				Access
	0x0000FFFFh	HALL_DPHI_MAX		Unsigned	
		Min	Max	Default	Unit
		0	65535	0	
Maximum dx for interpolation (default for digital hall: u16/6).					
0x39h	HALL_PHI_E_INTERPOLATED_PHI_E				R
	Mask	Name			Type
	0x0000FFFFh	HALL_PHI_E			Signed
		Min	Max	Default	Unit
		-32768	32767	0	
Raw electrical angle hall_phi_e of hall decoder, selection programmed via HALL_MODE control bit.					
	Mask	Name			Type
	0xFFFF0000h	HALL_PHI_E_INTERPOLATED			Signed
		Min	Max	Default	Unit
		-32768	32767	0	
Interpolated electrical angle hall_phi_e_interpolated, selection programmed via HALL_MODE control bit.					
0x3Ah	HALL_PHI_M				R
	Mask	Name			Type
	0x0000FFFFh	HALL_PHI_M			Signed
		Min	Max	Default	Unit
		-32768	32767	0	
Mechanical angle hall_phi_m of hall decoder.					
0x3Bh	AENC_DECODER_MODE				RW
	Mask	Name			Type
	0x00000001h	AENC_DECODER_MODE[0]			Bool
		Min	Max	Default	Unit
		0	1	0	
nXY_UVW : 0: SinCos Mode // 1: 0° 120° 240° Mode 0: off 1: on					
	Mask	Name			Type
	0x00001000h	AENC_DECODER_MODE[12]			Bool
		Min	Max	Default	Unit
		0	1	0	



Address	Registername				Access
	decoder count direction 0: positive 1: negative				
0x3Ch	AENC_DECODER_N_THRESHOLD				RW
	Mask	Name		Type	
	0x0000FFFFh	AENC_DECODER_N_THRESHOLD		Signed	
	Min	Max	Default	Unit	
-32768 32767 0					
Threshold for generating of N pulse from analog AENC_N signal (only needed for analog SinCos encoders with analog N signal).					
0x3Dh	AENC_DECODER_PHI_A_RAW				R
	Mask	Name		Type	
	0x0000FFFFh	AENC_DECODER_PHI_A_RAW		Signed	
	Min	Max	Default	Unit	
-32768 32767 0					
Raw analog angle phi calculated from analog AENC inputs (analog hall, analog SinCos, ...).					
0x3Eh	AENC_DECODER_PHI_A_OFFSET				RW
	Mask	Name		Type	
	0x0000FFFFh	AENC_DECODER_PHI_A_OFFSET		Signed	
	Min	Max	Default	Unit	
-32768 32767 0					
Offset for angle phi from analog decoder (analog hall, analog SinCos, ...).					
0x3Fh	AENC_DECODER_PHI_A				R
	Mask	Name		Type	
	0x0000FFFFh	AENC_DECODER_PHI_A		Signed	
	Min	Max	Default	Unit	
-2147483648 2147483647 0					
Resulting phi available for the FOC (phi_e might need to be calculated from this angle via aenc_decoder_ppr, for analog hall sensors phi_a might be used directly as phi_e depends on analog hall signal type).					
0x40h	AENC_DECODER_PPR				RW
	Mask	Name		Type	
	0x0000FFFFh	AENC_DECODER_PPR		Signed	
	Min	Max	Default	Unit	



Address	Registername				Access
	-32768	32767	1		
	Number of periods per revolution also called lines per revolution (different nomenclature compared to digital ABN encoders).				
0x41 _h	AENC_DECODER_COUNT				RW
	Mask	Name		Type	
	0xFFFFFFFF _h	AENC_DECODER_COUNT		Signed	
	Min	Max	Default	Unit	
	-2147483648	2147483647	0		
	Decoder position, raw unscaled.				
0x42 _h	AENC_DECODER_COUNT_N				RW
	Mask	Name		Type	
	0xFFFFFFFF _h	AENC_DECODER_COUNT_N		Signed	
	Min	Max	Default	Unit	
	-2147483648	2147483647	0		
	Latched decoder position on analog N pulse event.				
0x43 _h	AENC_DECODER_COUNT_N_MASK				RW
	Mask	Name		Type	
	0x0000FFFF _h	AENC_DECODER_COUNT_N_MASK		Signed	
	Min	Max	Default	Unit	
	-32768	32767	0		
	Optional position mask (position) for the analog N pulse within phi_a period to be and-ed with the digital N pulse generated via aenc_decoder_n_threshold.				
0x45 _h	AENC_DECODER_PHI_E_PHI_M_OFFSET				RW
	Mask	Name		Type	
	0x0000FFFF _h	AENC_DECODER_PHI_M_OFFSET		Signed	
	Min	Max	Default	Unit	
	-32768	32767	0		
	Offset for mechanical angle phi_m.				
	Mask	Name		Type	
	0xFFFF0000 _h	AENC_DECODER_PHI_E_OFFSET		Signed	
	Min	Max	Default	Unit	
	-32768	32767	0		
	Offset for electrical angle phi_e.				
0x46 _h	AENC_DECODER_PHI_E_PHI_M				R
	Mask	Name		Type	



Address	Registername				Access
	0x0000FFFFh	AENC_DECODER_PHI_M	Signed		
		Min	Max	Default	Unit
		-32768	32767	0	
		Resulting angle phi_m.			
	Mask	Name			Type
	0xFFFF0000h	AENC_DECODER_PHI_E			Signed
		Min	Max	Default	Unit
		-32768	32767	0	
		Resulting angle phi_e.			
0x47h	AENC_DECODER_POSITION				RW
	Mask	Name			Type
	0xFFFFFFFFh	AENC_DECODER_POSITION			Signed
		Min	Max	Default	Unit
		-2147483648	2147483647	0	
		Multi-turn position.			
0x50h	VELOCITY_SELECTION				RW
	Mask	Name			Type
	0x000000FFh	VELOCITY_SELECTION			Choice
		Min	Max	Default	Unit
		0	12	0	
		0: phi_e selected via PHI_E_SELECTION			
		1: phi_e_ext			
		2: phi_e_openloop			
		3: phi_e_abn			
		4: reserved			
		5: phi_e_hal			
		6: phi_e_aenc			
		7: phi_a_aenc			
		8: reserved			
		9: phi_m_abn			
		10: phi_m_abn_2			
		11: phi_m_aenc			
		12: phi_m_hal			
0x51h	POSITION_SELECTION				RW
	Mask	Name			Type

Address	Registername				Access
	0x000000FF _h	POSITION_SELECTION			Choice Unit
		Min	Max	Default	
		0	12	0	
		0: phi_e selected via PHI_E_SELECTION 1: phi_e_ext 2: phi_e_openloop 3: phi_e_abn 4: reserved 5: phi_e_hal 6: phi_e_aenc 7: phi_a_aenc 8: reserved 9: phi_m_abn 10: phi_m_abn_2 11: phi_m_aenc 12: phi_m_hal			
0x52 _h	PHI_E_SELECTION				RW
	Mask	Name			
	0x000000FF _h	PHI_E_SELECTION			Choice Unit
		Min	Max	Default	
		0	7	0	
		0: reserved 1: phi_e_ext 2: phi_e_openloop 3: phi_e_abn 4: reserved 5: phi_e_hal 6: phi_e_aenc 7: phi_a_aenc			
0x53 _h	PHI_E				R
	Mask	Name			
	0x0000FFFF _h	PHI_E			Signed Unit
		Min	Max	Default	
		-32768	32767	0	
		Angle used for the inner FOC loop.			

Address	Registername				Access
0x54h	PID_FLUX_P_FLUX_I				RW
	Mask	Name		Type	
	0x0000FFFFh	PID_FLUX_I		Signed	
	Min	Max	Default	Unit	
	0	32767	0		
	Mask	Name		Type	
	0xFFFF0000h	PID_FLUX_P		Signed	
	Min	Max	Default	Unit	
	0	32767	0		
0x55h	PID_FLUX_D				RW
	Mask	Name		Type	
	0x0000FFFFh	PID_FLUX_D		Signed	
	Min	Max	Default	Unit	
	0	32767	0		
0x56h	PID_TORQUE_P_TORQUE_I				RW
	Mask	Name		Type	
	0x0000FFFFh	PID_TORQUE_I		Signed	
	Min	Max	Default	Unit	
	0	32767	0		
	Mask	Name		Type	
	0xFFFF0000h	PID_TORQUE_P		Signed	
	Min	Max	Default	Unit	
	0	32767	0		
0x57h	PID_TORQUE_D				RW
	Mask	Name		Type	
	0x0000FFFFh	PID_TORQUE_D		Signed	
	Min	Max	Default	Unit	
	0	32767	0		
0x58h	PID_VELOCITY_P_VELOCITY_I				RW
	Mask	Name		Type	
	0x0000FFFFh	PID_VELOCITY_I		Signed	
	Min	Max	Default	Unit	
	0	32767	0		
	Mask	Name		Type	
	0xFFFF0000h	PID_VELOCITY_P		Signed	



Address	Registername					Access
		Min	Max	Default	Unit	
0x59h	PID_VELOCITY_D					RW
	Mask	Name			Type	
	0x0000FFFFh	PID_VELOCITY_D			Signed	
	Min	Max	Default	Unit		
0x5Ah		0	32767	0		
PID_POSITION_P_POSITION_I					RW	
Mask	Name			Type		
0x0000FFFFh	PID_POSITION_I			Signed		
Min	Max	Default	Unit			
	0	32767	0			
Mask	Name			Type		
0x5Bh	0xFFFF0000h	PID_POSITION_P			Signed	RW
	Min	Max	Default	Unit		
		0	32767	0		
0x5Ch	PID_TORQUE_FLUX_TARGET_DDT_LIMITS					RW
	Mask	Name			Type	
	0xFFFFFFFFh	PID_TORQUE_FLUX_TARGET_DDT_LIMITS			Unsigned	
	Min	Max	Default	Unit		
0x5Dh		0	32767	32767	[1/?s]	
Limits of change in time [d/dt] of the target torque and target flux.						
PIDOUT_UQ_UD_LIMITS						
	Mask	Name			Type	RW
	0x0000FFFFh	PIDOUT_UQ_UD_LIMITS			Unsigned	
	Min	Max	Default	Unit		
0x5Eh		0	32767	0		
Two dimensional circular limiter for inputs of iPark.						



Address	Registername				Access
	Mask	Name		Type	
0x0000FFFFh	0x0000FFFFh	PID_TORQUE_FLUX_LIMITS		Unsigned	
		Min	Max	Default	
		0	32767	0	
		PID torque limit and PID flux limit, limits the target values coming from the target registers.			
0x5Fh	PID_ACCELERATION_LIMIT				RW
	Mask	Name		Type	
	0xFFFFFFFFh	PID_ACCELERATION_LIMIT		Unsigned	
		Min	Max	Default	
		0	4294967295	0	
Acceleration limit.					
0x60h	PID_VELOCITY_LIMIT				RW
	Mask	Name		Type	
	0xFFFFFFFFh	PID_VELOCITY_LIMIT		Unsigned	
		Min	Max	Default	
		0	4294967295	0	
Velocity limit.					
0x61h	PID_POSITION_LIMIT_LOW				RW
	Mask	Name		Type	
	0xFFFFFFFFh	PID_POSITION_LIMIT_LOW		Signed	
		Min	Max	Default	
		-2147483648	2147483647	0	
Position limit low, programmable position barrier.					
0x62h	PID_POSITION_LIMIT_HIGH				RW
	Mask	Name		Type	
	0xFFFFFFFFh	PID_POSITION_LIMIT_HIGH		Signed	
		Min	Max	Default	
		-2147483648	2147483647	0	
Position limit high, programmable position barrier.					
0x63h	MODE_RAMP_MODE_MOTION				RW
	Mask	Name		Type	
	0x000000FFh	MODE_MOTION		Choice	
		Min	Max	Default	
		0	8	0	



Address	Registername				Access	
	0: stopped_mode 1: torque_mode 2: velocity_mode 3: position_mode 4: reserved 5: reserved 6: reserved 7: reserved 8: uq_ud_ext					
Mask	Name			Type		
0x0000FF00 _h	MODE_RAMP			Choice		
	Min	Max	Default	Unit		
0		7	0			
0: no velocity ramping 1: reserved 2: reserved 3: reserved 4: reserved 5: reserved 6: reserved 7: reserved						
0x64 _h	PID_TORQUE_FLUX_TARGET				RW	
	Mask	Name				
	0x0000FFFF _h	PID_FLUX_TARGET				
		Min	Max	Default		
	-32768		32767	0		
	Mask	Name				
	0xFFFF0000 _h	PID_TORQUE_TARGET				
		Min	Max	Default		
-32768		32767	0			
0x65 _h	PID_TORQUE_FLUX_OFFSET				RW	
	Mask	Name				
	0x0000FFFF _h	PID_FLUX_OFFSET				
		Min	Max	Default		
	-32768		32767	0		

Address	Registername				Access
	Flux offset for feed forward control.				
Mask	Name			Type	
0xFFFF0000 _h	PID_TORQUE_OFFSET			Signed	
	Min	Max	Default	Unit	
	-32768	32767	0		
	Torque offset for feed forward control.				
0x66 _h	PID_VELOCITY_TARGET				RW
Mask	Name			Type	
0xFFFFFFFF _h	PID_VELOCITY_TARGET			Signed	
	Min	Max	Default	Unit	
	-2147483648	2147483647	0		
	Target velocity register (for velocity mode).				
0x67 _h	PID_VELOCITY_OFFSET				RW
Mask	Name			Type	
0xFFFFFFFF _h	PID_VELOCITY_OFFSET			Signed	
	Min	Max	Default	Unit	
	-2147483648	2147483647	0		
	Velocity offset for feed forward control.				
0x68 _h	PID_POSITION_TARGET				RW
Mask	Name			Type	
0xFFFFFFFF _h	PID_POSITION_TARGET			Signed	
	Min	Max	Default	Unit	
	-2147483648	2147483647	0		
	Target position register (for position mode).				
0x69 _h	PID_TORQUE_FLUX_ACTUAL				R
Mask	Name			Type	
0x0000FFFF _h	PID_FLUX_ACTUAL			Signed	
	Min	Max	Default	Unit	
	-32768	32767	0		
Mask	Name			Type	
0xFFFF0000 _h	PID_TORQUE_ACTUAL			Signed	
	Min	Max	Default	Unit	
	-32768	32767	0		
0x6A _h	PID_VELOCITY_ACTUAL				R
Mask	Name			Type	

Address	Registername				Access
	0xFFFFFFFFh	PID_VELOCITY_ACTUAL	Signed		
		Min	Max	Default	Unit
		-2147483648	2147483647	0	
	Actual velocity.				
0x6Bh	PID_POSITION_ACTUAL				RW
	Mask	Name		Type	
	0xFFFFFFFFh	PID_POSITION_ACTUAL		Signed	
		Min	Max	Default	Unit
		-2147483648	2147483647	0	
	Actual multi turn position for positioning. WRITE on PID_POSITION_ACTUAL writes same value into PID_POSITION_TARGET to avoid unwanted move.				
0x6Ch	PID_ERROR_DATA				R
	Variant 0				
	Mask	Name		Type	
	0xFFFFFFFFh	PID_TORQUE_ERROR		Signed	
		Min	Max	Default	Unit
		-2147483648	2147483647	0	
	PID torque error.				
	Variant 1				
	Mask	Name		Type	
	0xFFFFFFFFh	PID_FLUX_ERROR		Signed	
		Min	Max	Default	Unit
		-2147483648	2147483647	0	
	PID flux error.				
	Variant 2				
	Mask	Name		Type	
	0xFFFFFFFFh	PID_VELOCITY_ERROR		Signed	
		Min	Max	Default	Unit
		-2147483648	2147483647	0	
	PID velocity error.				
	Variant 3				
	Mask	Name		Type	
	0xFFFFFFFFh	PID_POSITION_ERROR		Signed	
		Min	Max	Default	Unit



Address	Registername				Access
	-2147483648	2147483647	0		
PID position error.					
Variant 4					
Mask	Name			Type	
0xFFFFFFFFh	PID_TORQUE_ERROR_SUM			Signed	
	Min	Max	Default	Unit	
	-2147483648	2147483647	0		
PID torque error.					
Variant 5					
Mask	Name			Type	
0xFFFFFFFFh	PID_FLUX_ERROR_SUM			Signed	
	Min	Max	Default	Unit	
	-2147483648	2147483647	0		
PID flux error sum.					
Variant 6					
Mask	Name			Type	
0xFFFFFFFFh	PID_VELOCITY_ERROR_SUM			Signed	
	Min	Max	Default	Unit	
	-2147483648	2147483647	0		
PID velocity error sum.					
Variant 7					
Mask	Name			Type	
0xFFFFFFFFh	PID_POSITION_ERROR_SUM			Signed	
	Min	Max	Default	Unit	
	-2147483648	2147483647	0		
PID position error sum.					
0x6Dh	PID_ERROR_ADDR				RW
Mask	Name			Type	
0x000000FFh	PID_ERROR_ADDR			Choice	
	Min	Max	Default	Unit	
	0	7	0		
0: PID_TORQUE_ERROR 1: PID_FLUX_ERROR 2: PID_VELOCITY_ERROR 3: PID_POSITION_ERROR					



Address	Registername				Access
	4: PID_TORQUE_ERROR_SUM 5: PID_FLUX_ERROR_SUM 6: PID_VELOCITY_ERROR_SUM 7: PID_POSITION_ERROR_SUM				
0x6E _h	INTERIM_DATA				RW
	Variant 0				
	Mask	Name			Type
	0xFFFFFFFF _h	PIDIN_TARGET_TORQUE			Signed
		Min	Max	Default	Unit
		-2147483648	2147483647	0	
	PIDIN target torque.				
	Variant 1				
	Mask	Name			Type
	0xFFFFFFFF _h	PIDIN_TARGET_FLUX			Signed
		Min	Max	Default	Unit
		-2147483648	2147483647	0	
	PIDIN target flux.				
	Variant 2				
	Mask	Name			Type
	0xFFFFFFFF _h	PIDIN_TARGET_VELOCITY			Signed
		Min	Max	Default	Unit
		-2147483648	2147483647	0	
	PIDIN target velocity.				
	Variant 3				
	Mask	Name			Type
	0xFFFFFFFF _h	PIDIN_TARGET_POSITION			Signed
		Min	Max	Default	Unit
		-2147483648	2147483647	0	
	PIDIN target position.				
	Variant 4				
	Mask	Name			Type
	0xFFFFFFFF _h	PIDOUT_TARGET_TORQUE			Signed
		Min	Max	Default	Unit
		-2147483648	2147483647	0	
	PIDOUT target torque.				



Address	Registername				Access
	Variant 5				
Mask	Name			Type	
0xFFFFFFFFF _h	PIDOUT_TARGET_FLUX			Signed	
	Min	Max	Default	Unit	
	-2147483648	2147483647	0		
PIDOUT target flux.					
	Variant 6				
Mask	Name			Type	
0xFFFFFFFFF _h	PIDOUT_TARGET_VELOCITY			Signed	
	Min	Max	Default	Unit	
	-2147483648	2147483647	0		
PIDOUT target velocity.					
	Variant 7				
Mask	Name			Type	
0xFFFFFFFFF _h	PIDOUT_TARGET_POSITION			Signed	
	Min	Max	Default	Unit	
	-2147483648	2147483647	0		
PIDOUT target position.					
	Variant 8				
Mask	Name			Type	
0x0000FFFF _h	FOC_IUX			Signed	
	Min	Max	Default	Unit	
	-32768	32767	0		
Mask	Name			Type	
0xFFFF0000 _h	FOC_IWY			Signed	
	Min	Max	Default	Unit	
	-32768	32767	0		
	Variant 9				
Mask	Name			Type	
0x0000FFFF _h	FOC_IV			Signed	
	Min	Max	Default	Unit	
	-32768	32767	0		
	Variant 10				
Mask	Name			Type	
0x0000FFFF _h	FOC_IA			Signed	



Address	Registername					Access
	Min	Max	Default	Unit		
	-32768	32767	0			
Mask	Name			Type		
0xFFFF0000 _h	FOC_IB			Signed		
	Min	Max	Default	Unit		
	-32768	32767	0			
Variant 11						
Mask	Name			Type		
0x0000FFFF _h	FOC_ID			Signed		
	Min	Max	Default	Unit		
	-32768	32767	0			
Mask	Name			Type		
0xFFFF0000 _h	FOC_IQ			Signed		
	Min	Max	Default	Unit		
	-32768	32767	0			
Variant 12						
Mask	Name			Type		
0x0000FFFF _h	FOC_UD			Signed		
	Min	Max	Default	Unit		
	-32768	32767	0			
Mask	Name			Type		
0xFFFF0000 _h	FOC_UQ			Signed		
	Min	Max	Default	Unit		
	-32768	32767	0			
Variant 13						
Mask	Name			Type		
0x0000FFFF _h	FOC_UD_LIMITED			Signed		
	Min	Max	Default	Unit		
	-32768	32767	0			
Mask	Name			Type		
0xFFFF0000 _h	FOC_UQ_LIMITED			Signed		
	Min	Max	Default	Unit		
	-32768	32767	0			
Variant 14						
Mask	Name			Type		

Address	Registername				Access
0x0000FFFFh	FOC_UA		Signed		
	Min	Max	Default	Unit	
	-32768	32767	0		
Mask	Name		Type		
0xFFFF0000h	FOC_UB		Signed		
	Min	Max	Default	Unit	
	-32768	32767	0		
Variant 15					
Mask	Name		Type		
0x0000FFFFh	FOC_UUX		Signed		
	Min	Max	Default	Unit	
	-32768	32767	0		
Mask	Name		Type		
0xFFFF0000h	FOC_UWY		Signed		
	Min	Max	Default	Unit	
	-32768	32767	0		
Variant 16					
Mask	Name		Type		
0x0000FFFFh	FOC_UV		Signed		
	Min	Max	Default	Unit	
	-32768	32767	0		
Variant 17					
Mask	Name		Type		
0x0000FFFFh	PWM_UX		Signed		
	Min	Max	Default	Unit	
	-32768	32767	0		
Mask	Name		Type		
0xFFFF0000h	PWM_WY		Signed		
	Min	Max	Default	Unit	
	-32768	32767	0		
Variant 18					
Mask	Name		Type		
0x0000FFFFh	PWM_V		Signed		
	Min	Max	Default	Unit	
	-32768	32767	0		



Address	Registername				Access
	Variant 19				
Mask	Name			Type	
0x0000FFFF _h	ADC_I_0			Signed	
	Min	Max	Default	Unit	
	-32768	32767	0		
Mask	Name			Type	
0xFFFF0000 _h	ADC_I_1			Signed	
	Min	Max	Default	Unit	
	-32768	32767	0		
Variant 192					
Mask	Name			Type	
0x0000FFFF _h	DEBUG_VALUE_0			Signed	
	Min	Max	Default	Unit	
	-32768	32767	0		
Mask	Name			Type	
0xFFFF0000 _h	DEBUG_VALUE_1			Signed	
	Min	Max	Default	Unit	
	-32768	32767	0		
Variant 193					
Mask	Name			Type	
0x0000FFFF _h	DEBUG_VALUE_2			Signed	
	Min	Max	Default	Unit	
	-32768	32767	0		
Mask	Name			Type	
0xFFFF0000 _h	DEBUG_VALUE_3			Signed	
	Min	Max	Default	Unit	
	-32768	32767	0		
Variant 194					
Mask	Name			Type	
0x0000FFFF _h	DEBUG_VALUE_4			Signed	
	Min	Max	Default	Unit	
	-32768	32767	0		
Mask	Name			Type	
0xFFFF0000 _h	DEBUG_VALUE_5			Signed	
	Min	Max	Default	Unit	



Address	Registername				Access
	-32768	32767	0		
	Variant 195				
Mask	Name				Type
0x0000FFFFh	DEBUG_VALUE_6				Signed
	Min	Max	Default		Unit
	-32768	32767	0		
Mask	Name				Type
0xFFFF0000h	DEBUG_VALUE_7				Signed
	Min	Max	Default		Unit
	-32768	32767	0		
	Variant 196				
Mask	Name				Type
0x0000FFFFh	DEBUG_VALUE_8				Unsigned
	Min	Max	Default		Unit
	0	65535	0		
Mask	Name				Type
0xFFFF0000h	DEBUG_VALUE_9				Unsigned
	Min	Max	Default		Unit
	0	65535	0		
	Variant 197				
Mask	Name				Type
0x0000FFFFh	DEBUG_VALUE_10				Unsigned
	Min	Max	Default		Unit
	0	65535	0		
Mask	Name				Type
0xFFFF0000h	DEBUG_VALUE_11				Unsigned
	Min	Max	Default		Unit
	0	65535	0		
	Variant 198				
Mask	Name				Type
0x0000FFFFh	DEBUG_VALUE_12				Unsigned
	Min	Max	Default		Unit
	0	65535	0		
Mask	Name				Type
0xFFFF0000h	DEBUG_VALUE_13				Unsigned



Address	Registername					Access
	Min	Max	Default	Unit		
	Variant 199					
Mask	Name			Type		
0x0000FFFF _h	DEBUG_VALUE_14			Unsigned		
	Min	Max	Default	Unit		
	0	65535	0			
Mask	Name			Type		
0xFFFF0000 _h	DEBUG_VALUE_15			Unsigned		
	Min	Max	Default	Unit		
	0	65535	0			
	Variant 200					
Mask	Name			Type		
0xFFFFFFFF _h	DEBUG_VALUE_16			Signed		
	Min	Max	Default	Unit		
	-2147483648	2147483647	0			
	Variant 201					
Mask	Name			Type		
0xFFFFFFFF _h	DEBUG_VALUE_17			Signed		
	Min	Max	Default	Unit		
	-2147483648	2147483647	0			
	Variant 202					
Mask	Name			Type		
0xFFFFFFFF _h	DEBUG_VALUE_18			Signed		
	Min	Max	Default	Unit		
	-2147483648	2147483647	0			
	Variant 203					
Mask	Name			Type		
0xFFFFFFFF _h	DEBUG_VALUE_19			Signed		
	Min	Max	Default	Unit		
	-2147483648	2147483647	0			
0x6F _h	INTERIM_ADDR					RW
	Mask	Name			Type	
	0x000000FF _h	INTERIM_ADDR			Choice	
		Min	Max	Default	Unit	

Address	Registername				Access
	0	203	0		
	0: PIDIN_TARGET_TORQUE				
	1: PIDIN_TARGET_FLUX				
	2: PIDIN_TARGET_VELOCITY				
	3: PIDIN_TARGET_POSITION				
	4: PIDOUT_TARGET_TORQUE				
	5: PIDOUT_TARGET_FLUX				
	6: PIDOUT_TARGET_VELOCITY				
	7: PIDOUT_TARGET_POSITION				
	8: FOC_IWY_IUX				
	9: FOC_IV				
	10: FOC_IB_IA				
	11: FOC_IQ_ID				
	12: FOC_UQ_UD				
	13: FOC_UQ_UD_LIMITED				
	14: FOC_UB_UA				
	15: FOC_UWY_UUX				
	16: FOC_UV				
	17: PWM_WY_UX				
	18: PWM_UV				
	19: ADC_I1_I0				
	192: DEBUG_VALUE_1_0				
	193: DEBUG_VALUE_3_2				
	194: DEBUG_VALUE_5_4				
	195: DEBUG_VALUE_7_6				
	196: DEBUG_VALUE_9_8				
	197: DEBUG_VALUE_11_10				
	198: DEBUG_VALUE_13_12				
	199: DEBUG_VALUE_15_14				
	200: DEBUG_VALUE_16				
	201: DEBUG_VALUE_17				
	202: DEBUG_VALUE_18				
	203: DEBUG_VALUE_19				
0x75 _h	ADC_VM_LIMITS				RW
	Mask	Name	Type		



Address	Registername				Access
0x0000FFFFh	ADC_VM_LIMIT_LOW	Min	Max	Default	Unsigned Unit
	0	65535	0		
	Low limit for brake chopper output BRAKE_OUT.				
Mask	Name			Type	
0xFFFF0000h	ADC_VM_LIMIT_HIGH	Min	Max	Default	Unsigned Unit
	0	65535	0		
	High limit for brake chopper output BRAKE_OUT.				
0x76h	TMC4670_INPUTS_RAW				R
Mask	Name			Type	
0x00000001h	TMC4670_INPUTS_RAW[0]	Min	Max	Default	Bool Unit
	0	1	0		
	A of ABN_RAW				
	0: off				
	1: on				
Mask	Name			Type	
0x00000002h	TMC4670_INPUTS_RAW[1]	Min	Max	Default	Bool Unit
	0	1	0		
	B of ABN_RAW				
	0: off				
	1: on				
Mask	Name			Type	
0x00000004h	TMC4670_INPUTS_RAW[2]	Min	Max	Default	Bool Unit
	0	1	0		
	N of ABN_RAW				
	0: off				
	1: on				
Mask	Name			Type	
0x00000008h	TMC4670_INPUTS_RAW[3]	Min	Max	Default	Bool Unit
	0	1	0		



Address	Registername				Access
	— 0: off 1: on				
Mask	Name			Type	
0x00000010h	TMC4670_INPUTS_RAW[4]			Bool	
	Min	Max	Default	Unit	
	0	1	0		
	A of ABN_2_RAW 0: off 1: on				
Mask	Name			Type	
0x00000020h	TMC4670_INPUTS_RAW[5]			Bool	
	Min	Max	Default	Unit	
	0	1	0		
	B of ABN_2_RAW 0: off 1: on				
Mask	Name			Type	
0x00000040h	TMC4670_INPUTS_RAW[6]			Bool	
	Min	Max	Default	Unit	
	0	1	0		
	N of ABN_2_RAW 0: off 1: on				
Mask	Name			Type	
0x00000080h	TMC4670_INPUTS_RAW[7]			Bool	
	Min	Max	Default	Unit	
	0	1	0		
	— 0: off 1: on				
Mask	Name			Type	
0x00000100h	TMC4670_INPUTS_RAW[8]			Bool	
	Min	Max	Default	Unit	
	0	1	0		



Address	Registername				Access
	HALL_UX of HALL_RAW 0: off 1: on				
Mask	Name			Type	
0x00000200h	TMC4670_INPUTS_RAW[9]			Bool	
	Min	Max	Default	Unit	
	0	1	0		
	HALL_V of HALL_RAW 0: off 1: on				
Mask	Name			Type	
0x00000400h	TMC4670_INPUTS_RAW[10]			Bool	
	Min	Max	Default	Unit	
	0	1	0		
	HALL_WY of HALL_RAW 0: off 1: on				
Mask	Name			Type	
0x00000800h	TMC4670_INPUTS_RAW[11]			Bool	
	Min	Max	Default	Unit	
	0	1	0		
	—				
	0: off				
	1: on				
Mask	Name			Type	
0x00001000h	TMC4670_INPUTS_RAW[12]			Bool	
	Min	Max	Default	Unit	
	0	1	0		
	REF_SW_R_RAW 0: off 1: on				
Mask	Name			Type	
0x00002000h	TMC4670_INPUTS_RAW[13]			Bool	
	Min	Max	Default	Unit	
	0	1	0		



Address	Registername				Access
	REF_SW_H_RAW 0: off 1: on				
Mask	Name			Type	
0x00004000 _h	TMC4670_INPUTS_RAW[14]			Bool	
	Min	Max	Default	Unit	
	0	1	0		
	REF_SW_L_RAW 0: off 1: on				
Mask	Name			Type	
0x00008000 _h	TMC4670_INPUTS_RAW[15]			Bool	
	Min	Max	Default	Unit	
	0	1	0		
	ENABLE_IN_RAW 0: off 1: on				
Mask	Name			Type	
0x00010000 _h	TMC4670_INPUTS_RAW[16]			Bool	
	Min	Max	Default	Unit	
	0	1	0		
	STP of DIRSTP_RAW 0: off 1: on				
Mask	Name			Type	
0x00020000 _h	TMC4670_INPUTS_RAW[17]			Bool	
	Min	Max	Default	Unit	
	0	1	0		
	DIR of DIRSTP_RAW 0: off 1: on				
Mask	Name			Type	
0x00040000 _h	TMC4670_INPUTS_RAW[18]			Bool	
	Min	Max	Default	Unit	
	0	1	0		

Address	Registername				Access
	PWM_IN_RAW 0: off 1: on				
Mask	Name			Type	
0x00080000 _h	TMC4670_INPUTS_RAW[19]			Bool	
	Min	Max	Default	Unit	
	0	1	0		
	—				
	0: off 1: on				
Mask	Name			Type	
0x00100000 _h	TMC4670_INPUTS_RAW[20]			Bool	
	Min	Max	Default	Unit	
	0	1	0		
	ESI_0 of ESI_RAW 0: off 1: on				
Mask	Name			Type	
0x00200000 _h	TMC4670_INPUTS_RAW[21]			Bool	
	Min	Max	Default	Unit	
	0	1	0		
	ESI_1 of ESI_RAW 0: off 1: on				
Mask	Name			Type	
0x00400000 _h	TMC4670_INPUTS_RAW[22]			Bool	
	Min	Max	Default	Unit	
	0	1	0		
	ESI_2 of ESI_RAW 0: off 1: on				
Mask	Name			Type	
0x00800000 _h	TMC4670_INPUTS_RAW[23]			Bool	
	Min	Max	Default	Unit	
	0	1	0		

Address	Registername				Access
	— 0: off 1: on				
Mask	Name			Type	
0x01000000 _h	TMC4670_INPUTS_RAW[24]			Bool	
	Min	Max	Default	Unit	
	0	1	0		
	CFG_0 of CFG 0: off 1: on				
Mask	Name			Type	
0x02000000 _h	TMC4670_INPUTS_RAW[25]			Bool	
	Min	Max	Default	Unit	
	0	1	0		
	CFG_1 of CFG 0: off 1: on				
Mask	Name			Type	
0x04000000 _h	TMC4670_INPUTS_RAW[26]			Bool	
	Min	Max	Default	Unit	
	0	1	0		
	CFG_2 of CFG 0: off 1: on				
Mask	Name			Type	
0x08000000 _h	TMC4670_INPUTS_RAW[27]			Bool	
	Min	Max	Default	Unit	
	0	1	0		
	CFG_3 of CFG 0: off 1: on				
Mask	Name			Type	
0x10000000 _h	TMC4670_INPUTS_RAW[28]			Bool	
	Min	Max	Default	Unit	
	0	1	0		

Address	Registername				Access
	PWM_IDLE_L_RAW 0: off 1: on				
Mask	Name			Type	
0x20000000h	TMC4670_INPUTS_RAW[29]			Bool	
	Min	Max	Default	Unit	
	0	1	0		
	PWM_IDLE_H_RAW 0: off 1: on				
Mask	Name			Type	
0x40000000h	TMC4670_INPUTS_RAW[30]			Bool	
	Min	Max	Default	Unit	
	0	1	0		
	DRV_ERR_IN_RAW 0: off 1: on				
Mask	Name			Type	
0x80000000h	TMC4670_INPUTS_RAW[31]			Bool	
	Min	Max	Default	Unit	
	0	1	0		
	— 0: off 1: on				
0x77h	TMC4670_OUTPUTS_RAW				
Mask	Name			Type	R
0x00000001h	TMC4670_OUTPUTS_RAW[0]			Bool	
	Min	Max	Default	Unit	
	0	1	0		
	PWM_UX1_L 0: off 1: on				
Mask	Name			Type	
0x00000002h	TMC4670_OUTPUTS_RAW[1]			Bool	
	Min	Max	Default	Unit	



Address	Registername				Access
	0	1	0		
	PWM_UX1_H				
	0: off				
	1: on				
Mask	Name			Type	
0x00000004 _h	TMC4670_OUTPUTS_RAW[2]			Bool	
	Min	Max	Default	Unit	
	0	1	0		
	PWM_VX2_L				
	0: off				
	1: on				
Mask	Name			Type	
0x00000008 _h	TMC4670_OUTPUTS_RAW[3]			Bool	
	Min	Max	Default	Unit	
	0	1	0		
	PWM_VX2_H				
	0: off				
	1: on				
Mask	Name			Type	
0x00000010 _h	TMC4670_OUTPUTS_RAW[4]			Bool	
	Min	Max	Default	Unit	
	0	1	0		
	PWM_WY1_L				
	0: off				
	1: on				
Mask	Name			Type	
0x00000020 _h	TMC4670_OUTPUTS_RAW[5]			Bool	
	Min	Max	Default	Unit	
	0	1	0		
	PWM_WY1_H				
	0: off				
	1: on				
Mask	Name			Type	
0x00000040 _h	TMC4670_OUTPUTS_RAW[6]			Bool	
	Min	Max	Default	Unit	

Address	Registername					Access
	0	1	0			
	PWM_Y2_L					
	0: off					
	1: on					
Mask	Name			Type		
0x00000080 _h	TMC4670_OUTPUTS_RAW[7]			Bool		
Min	Max	Default		Unit		
0	1	0				
PWM_Y2_H						
0: off						
1: on						
STATUS_FLAGS						RW
Mask	Name			Type		
0x00000001 _h	STATUS_FLAGS[0]			Bool		
Min	Max	Default		Unit		
0	1	0				
pid_x_target_limit						
0: off						
1: on						
Mask	Name			Type		
0x00000002 _h	STATUS_FLAGS[1]			Bool		
Min	Max	Default		Unit		
0	1	0				
pid_x_target_ddt_limit						
0: off						
1: on						
Mask	Name			Type		
0x00000004 _h	STATUS_FLAGS[2]			Bool		
Min	Max	Default		Unit		
0	1	0				
pid_x_errsum_limit						
0: off						
1: on						
Mask	Name			Type		
0x00000008 _h	STATUS_FLAGS[3]			Bool		

Address	Registername					Access
	Min	Max	Default	Unit		
	0	1	0			
	pid_x_output_limit					
	0: off 1: on					
Mask	Name			Type		
0x00000010 _h	STATUS_FLAGS[4]			Bool		
Min	Max	Default	Unit			
0	1	0				
	pid_v_target_limit					
	0: off 1: on					
Mask	Name			Type		
0x00000020 _h	STATUS_FLAGS[5]			Bool		
Min	Max	Default	Unit			
0	1	0				
	pid_v_target_ddt_limit					
	0: off 1: on					
Mask	Name			Type		
0x00000040 _h	STATUS_FLAGS[6]			Bool		
Min	Max	Default	Unit			
0	1	0				
	pid_v_errsum_limit					
	0: off 1: on					
Mask	Name			Type		
0x00000080 _h	STATUS_FLAGS[7]			Bool		
Min	Max	Default	Unit			
0	1	0				
	pid_v_output_limit					
	0: off 1: on					
Mask	Name			Type		
0x00000100 _h	STATUS_FLAGS[8]			Bool		

Address	Registername					Access
	Min	Max	Default	Unit		
	0	1	0			
	pid_id_target_limit					
	0: off 1: on					
Mask	Name			Type		
0x00000200 _h	STATUS_FLAGS[9]			Bool		
Min	Max	Default	Unit			
0	1	0				
	pid_id_target_ddt_limit					
	0: off 1: on					
Mask	Name			Type		
0x00000400 _h	STATUS_FLAGS[10]			Bool		
Min	Max	Default	Unit			
0	1	0				
	pid_id_errsum_limit					
	0: off 1: on					
Mask	Name			Type		
0x00000800 _h	STATUS_FLAGS[11]			Bool		
Min	Max	Default	Unit			
0	1	0				
	pid_id_output_limit					
	0: off 1: on					
Mask	Name			Type		
0x00001000 _h	STATUS_FLAGS[12]			Bool		
Min	Max	Default	Unit			
0	1	0				
	pid_iq_target_limit					
	0: off 1: on					
Mask	Name			Type		
0x00002000 _h	STATUS_FLAGS[13]			Bool		



Address	Registername					Access
	Min	Max	Default	Unit		
	0	1	0			
	pid_iq_target_ddt_limit					
	0: off 1: on					
Mask	Name			Type		
0x00004000 _h	STATUS_FLAGS[14]			Bool		
Min	Max	Default	Unit			
	0	1	0			
	pid_iq_errsum_limit					
	0: off 1: on					
Mask	Name			Type		
0x00008000 _h	STATUS_FLAGS[15]			Bool		
Min	Max	Default	Unit			
	0	1	0			
	pid_iq_output_limit					
	0: off 1: on					
Mask	Name			Type		
0x00010000 _h	STATUS_FLAGS[16]			Bool		
Min	Max	Default	Unit			
	0	1	0			
	ipark_cirlim_limit_u_d					
	0: off 1: on					
Mask	Name			Type		
0x00020000 _h	STATUS_FLAGS[17]			Bool		
Min	Max	Default	Unit			
	0	1	0			
	ipark_cirlim_limit_u_q					
	0: off 1: on					
Mask	Name			Type		
0x00040000 _h	STATUS_FLAGS[18]			Bool		

Address	Registername					Access
	Min	Max	Default	Unit		
	0	1	0			
	ipark_cirlim_limit_u_r					
	0: off 1: on					
Mask	Name			Type		
0x00080000 _h	STATUS_FLAGS[19]			Bool		
	Min	Max	Default	Unit		
	0	1	0			
	— 0: off 1: on					
Mask	Name			Type		
0x00100000 _h	STATUS_FLAGS[20]			Bool		
	Min	Max	Default	Unit		
	0	1	0			
	ref_sw_r					
	0: off 1: on					
Mask	Name			Type		
0x00200000 _h	STATUS_FLAGS[21]			Bool		
	Min	Max	Default	Unit		
	0	1	0			
	ref_sw_h					
	0: off 1: on					
Mask	Name			Type		
0x00400000 _h	STATUS_FLAGS[22]			Bool		
	Min	Max	Default	Unit		
	0	1	0			
	ref_sw_l					
	0: off 1: on					
Mask	Name			Type		
0x00800000 _h	STATUS_FLAGS[23]			Bool		



Address	Registername					Access
	Min	Max	Default	Unit		
	0	1	0			
	—					
	0: off					
	1: on					
Mask	Name			Type		
0x01000000 _h	STATUS_FLAGS[24]			Bool		
	Min	Max	Default	Unit		
	0	1	0			
	pwm_min					
	0: off					
	1: on					
Mask	Name			Type		
0x02000000 _h	STATUS_FLAGS[25]			Bool		
	Min	Max	Default	Unit		
	0	1	0			
	pwm_max					
	0: off					
	1: on					
Mask	Name			Type		
0x04000000 _h	STATUS_FLAGS[26]			Bool		
	Min	Max	Default	Unit		
	0	1	0			
	adc_i_clipped					
	0: off					
	1: on					
Mask	Name			Type		
0x08000000 _h	STATUS_FLAGS[27]			Bool		
	Min	Max	Default	Unit		
	0	1	0			
	aenc_clipped					
	0: off					
	1: on					
Mask	Name			Type		
0x10000000 _h	STATUS_FLAGS[28]			Bool		

Address	Registername					Access
		Min	Max	Default	Unit	
	enc_n	0	1	0		
	0: off					
	1: on					
Mask	Name			Type		
0x20000000 _h	STATUS_FLAGS[29]			Bool		
Min	Max	Default	Unit			
0	1	0				
enc_2_n						
0: off						
1: on						
Mask	Name			Type		
0x40000000 _h	STATUS_FLAGS[30]			Bool		
Min	Max	Default	Unit			
0	1	0				
aenc_n						
0: off						
1: on						
Mask	Name			Type		
0x80000000 _h	STATUS_FLAGS[31]			Bool		
Min	Max	Default	Unit			
0	1	0				
—						
0: off						
1: on						
0x7D _h	WARNING_MASK					RW
Mask	Name			Type		
0xFFFFFFFF _h	WARNING_MASK			Unsigned		
Min	Max	Default	Unit			
0	4294967295	0				
0x7E _h	ERROR_MASK					RW
Mask	Name			Type		
0xFFFFFFFF _h	ERROR_MASK			Unsigned		
Min	Max	Default	Unit			

Address	Registername			Access
	0	4294967295	0	

Table 6: Register Map for TMC4670



6 Pinning

Info

All power supply pins (1V2, 2V5, 3V3) must be connected.

All ground pins (GND, GND_REF) must be connected.

All pins specified as n.c. (=not connected) must be left open.

Analog inputs (AI) are 2.5V single ended inputs. Voltage dividers are required to scale down higher input voltages.

Digital inputs (I) resp. (IO) are 3.3V single ended inputs. Voltage dividers are required to scale down higher input voltages.

IO	Description
AI	analog input, 2.5V
I	digital input, 3.3V
IO	digital input or digital output, direction programmable, 3.3V
O	digital output, 3.3V

Table 7: Pin Type Definition



Name	Ball	IO	Description
nRST	B10	I	active low reset input
CLK	M3	I	clock input, 25 MHz
ENABLE_IN	T13	I	active high enable input
SPI_nSCS	R7	I	SPI active low chip select input
SPI_SCK	T7	I	SPI clock input
SPI_MOSI	T6	I	SPI master out slave input
SPI_MISO	R6	O	SPI master in slave output
ENC_A	L1	I	A input of incremental encoder
ENC_B	L2	I	B input of incremental encoder
ENC_N	M1	I	N input of incremental encoder
ENC2_A	R1	I	A input of incremental encoder
ENC2_B	P2	I	B input of incremental encoder
ENC2_N	P4	I	N input of incremental encoder
HALL_UX	N2	I	digital hall input H1 for 3-phase (U) or 2-phase (X)
HALL_V	N1	I	digital hall input H2 for 3-phase (V)
HALL_WY	M2	I	digital hall input H3 for 3-phase (W) or 2-phase (Y)
REF_SW_L	A9	I	Left (L) reference switch
REF_SW_H	A8	I	Home (H) reference switch
REF_SW_R	A10	I	Right (R) reference switch
AENC_UX	C1	AI	analog hall or analog encoder, 3-phase (U) or 2-phase (X (cos))
AENC_V	D1	AI	analog hall or analog encoder, 3-phase (V)
AENC_WY	E1	AI	analog hall or analog encoder, 3-phase (W) or 2-phase (Y (sin))
AENC_N	B1	AI	analog encoder N pulse input
ADC_I_0	F2	AI	phase current measurement voltage input I_0 (I_U, I_X)
ADC_I_1	F4	AI	phase current measurement voltage input I_1 (I_V, I_W, I_Y)
ADC_VM	E3	AI	analog input for motor supply voltage (VM) measurement
AGPI	G2	AI	Analog general purpose input (analog GPI)
ADC_T_MOSFETS	C3	AI	analog input for MOSFET temperature signal
ADC_T_MOTOR	C4	AI	analog input for motor temperature signal
ADC_U_UX	F1	AI	analog voltage input for terminal UX
ADC_U_V	F5	AI	analog voltage input for terminal V
ADC_U_WY	B2	A	analog voltage input for terminal WY
ADC_I_S	C2	AI	analog bottom current measurement voltage input, reserved
ADC_START	B5	O	ADC start pulse for TLC2351



Name	Ball	IO	Description
ADC_BIP	B4	O	output driving ADC LTC2351 BIP input
ADC_nSCS	B7	O	ADC LTC2351 nSCS signal
ADC_SCK	B6	O	ADC LTC2351 SCK signal
ADC_MISO	A6	I	from ADC LTC2351 SDO output
ADC_MOSI	A7	O	reserved for ADC w/ SDI input
PWM_IDLE_H	A11	I	Idle Level of high side gate control signals
PWM_IDLE_L	B11	I	Idle Level of low side gate control signals
PWM_UX1_H	D16	O	high side gate control output U (3-phase) resp. X1 (2-phase)
PWM_UX1_L	D15	O	low side gate control output U (3-phase) resp. X1 (2-phase)
PWM_VX2_H	C16	O	high side gate control output V (3-phase) resp. X2 (2-phase)
PWM_VX2_L	D14	O	low side gate control output V (3-phase) resp. X2 (2-phase)
PWM_WY1_H	B16	O	high side gate control output W (3-phase) resp. Y1 (2-phase)
PWM_WY1_L	C15	O	low side gate control output W (3-phase) resp. Y1 (2-phase)
PWM_Y2_H	B15	O	high side gate control output Y2 (2-phase only)
PWM_Y2_L	C14	O	low side gate control output Y2 (2-phase only)
PWM_Z_OUT	L15	O	pulse, indicating start of PWM period (zero count)
PWM_C_OUT	L16	O	pulse, indicating center of PWM period
BRAKE_OUT	A13	O	brake chopper control signal
DRV_ERR_IN	A12	I	driver error input (from gate driver)

Table 8: Functional Pin Description



Name	Ball	IO	Description reserved IOs not supported by current version
STP	T15	I	step input
DIR	T14	I	direction input
UART_DIR	P12	O	UART direction pin in case of RS485 usage
UART_TXD	P11	O	transmit data TXD (RS232, RS422, RS485, . . .)
UART_RXD	R11	I	receive data RXD (RS232, RS422, RS485, . . .)
ENC_SSI_CLK	R8	O	SSI clock (+) output
ENC_SSI_DAT	T8	I	SSI data (+) data input
SPI_DBG_CLK	P8	IO	DBG SPI master CLK
UART_RXD/SPI_DBG_MISO	T9	IO	DBG SPI master MISO
UART_TXD/SPI_DBG莫斯I	R9	IO	DBG SPI master MOSI
URAT_DIR/SPI_DBG_nSCS	P9	IO	DBG SPI mster nSCS
MCLK_UX	G16	IO	delta sigma modulator clock IO for phase current UX (programmable direction)
MDAT_UX	E16	I	delta sigma modulator data stream for phase UX
MCLK_WY	F16	IO	delta sigma modulator clock IO for phase current WY (programmable direction)
MDAT_WY	E14	I	delta sigma modulator data stream for phase WY
MCLK_S	G15	IO	delta sigma modulator clock IO for phase bottom current (programmable direction)
MDAT_S	E15	I	delta sigma modulator data stream for bottom current
CFG_0	T5	I	configuration pin#0
CFG_1	T4	I	configuration pin#1
CFG_2	T3	I	configuration pin#2
CFG_3	T2	I	configuration pin#3
ESI_0	H16	I	Emergency Switch Input #0
ESI_1	J15	I	Emergency Switch Input #1
ESI_2	J16	I	Emergency Switch Input #2
WARNING_OUT	P10	I	Maskable Warning Output
ERROR_OUT	T11	I	Maskable Error Output
ENABLE_OUT	A5	O	enable output
TRIGGER_OUT	K14	O	general purpose trigger output
GPIO_0	R5	IO	general purpose IO#0
GPIO_1	R4	IO	general purpose IO#1
GPIO_2	R3	IO	general purpose IO#2
GPIO_3	R2	IO	general purpose IO#3



Name	Ball	IO	Description reserved IOs not supported by current version
DBGIO_0	P15	IO	debug IO#0
DBGIO_1	N16	IO	debug IO#1
DBGIO_2	M15	IO	debug IO#2
DBGIO_3	M16	IO	debug IO#3
PWM_IN	R10	I	PWM input, to assign target values via duty cycle
DIAG_OUT_0	T12	O	DIAG_OUT_0 diagnosis output
DIAG_OUT_1	R12	O	DIAG_OUT_1 diagnosis output

Table 9: Description of pins not supported by current version



Name	Ball	IO	Supply Voltage Pins and Ground Pins
VCCIO3V3	K4	3.3V	
VCCIO3V3	L4	3.3V	
VCCIO3V3	N6	3.3V	
VCCIO3V3	N7	3.3V	
VCCIO3V3	N8	3.3V	
VCCIO3V3	N10	3.3V	
VCCIO3V3	N11	3.3V	
VCCIO3V3	K13	3.3V	
VCCIO3V3	L13	3.3V	
VCCIO3V3	M13	3.3V	
VCCIO3V3	F13	3.3V	
VCCIO3V3	G13	3.3V	
VCCIO3V3	H13	3.3V	
VCCIO3V3	J13	3.3V	
VCCIO3V3	D10	3.3V	
VCCIO3V3	D11	3.3V	
VCCIO3V3	C7	3.3V	
VCCIO3V3	D7	3.3V	
VCCIO3V3	D8	3.3V	
VCCrefR1	E8	3.3V via 10K	reference resistor to be connected to 3.3V supply voltage
VCCrefR2	F7	3.3V via 10K	reference resistor to be connected to 3.3V supply voltage
VCCrefR3	E7	3.3V via 10K	reference resistor to be connected to 3.3V supply voltage
ADCVREF2V5	E4	2.5V	
VCCA2V5	D5	2.5V	
VCCA2V5	E12	2.5V	
VCCA2V5	L5	2.5V	
VCCA2V5	M12	2.5V	
VCCA2V5	E5	2.5V	
VCCA2V5	G4	2.5V	
VCCA2V5	H4	2.5V	
VCCA2V5	J4	2.5V	
VCC1V2	G7	1.2V	
VCC1V2	G9	1.2V	
VCC1V2	H8	1.2V	



Name	Ball	IO	Supply Voltage Pins and Ground Pins
VCC1V2	H9	1.2V	
VCC1V2	H10	1.2V	
VCC1V2	J7	1.2V	
VCC1V2	J8	1.2V	
VCC1V2	J9	1.2V	
VCC1V2	K8	1.2V	
VCC1V2	K10	1.2V	
VCCINT1V2	F6	1.2V	
VCCPLL1V2	D4	1.2V	
VCCPLL1V2	D13	1.2V	
VCCPLL1V2	M5	1.2V	
VCCPLL1V2	N13	1.2V	
GND	A1	0V	
GND	A16	0V	
GND	B14	0V	
GND	C8	0V	
GND	C11	0V	
GND	D2	0V	
GND	D3	0V	
GND	D6	0V	
GND	E6	0V	
GND	E13	0V	
GND	F8	0V	
GND	F15	0V	
GND	F3	0V	
GND	G3	0V	
GND	G8	0V	
GND	G10	0V	
GND	H7	0V	
GND	H14	0V	
GND	J10	0V	
GND	K1	0V	
GND	K3	0V	
GND	K7	0V	



Name	Ball	IO	Supply Voltage Pins and Ground Pins
GND	K9	0V	
GND	K16	0V	
GND	L14	0V	
GND	M4	0V	
GND	N9	0V	
GND	N12	0V	
GND	N15	0V	
GND	P3	0V	
GND	P7	0V	
GND	R13	0V	
GND	T1	0V	
GND	T10	0V	
GND	T16	0V	
REFGND	E2	0V	

Table 10: Supply Voltage Pins and Ground Pins



Name	Ball	IO	Not Connected (n.c.) Pins
n.c.	A2	-	not connected
n.c.	A3	-	not connected
n.c.	A4	-	not connected
n.c.	A14	-	not connected
n.c.	A15	-	not connected
n.c.	B3	-	not connected
n.c.	B8	-	not connected
n.c.	B9	-	not connected
n.c.	B12	-	not connected
n.c.	B13	-	not connected
n.c.	C5	-	not connected
n.c.	C6	-	not connected
n.c.	C9	-	not connected
n.c.	C10	-	not connected
n.c.	C12	-	not connected
n.c.	C13	-	not connected
n.c.	D9	-	not connected
n.c.	D12	-	not connected
n.c.	E9	-	not connected
n.c.	E10	-	not connected
n.c.	E11	-	not connected
n.c.	F9	-	not connected
n.c.	F10	-	not connected
n.c.	F11	-	not connected
n.c.	F12	-	not connected
n.c.	F14	-	not connected
n.c.	G5	-	not connected
n.c.	G1	-	not connected
n.c.	G11	-	not connected
n.c.	G12	-	not connected
n.c.	G14	-	not connected
n.c.	G6	-	not connected
n.c.	H5	-	not connected
n.c.	H6	-	not connected



Name	Ball	IO	Not Connected (n.c.) Pins
n.c.	H1	-	not connected
n.c.	H11	-	not connected
n.c.	H12	-	not connected
n.c.	H15	-	not connected
n.c.	H2	-	not connected
n.c.	H3	-	not connected
n.c.	J1	-	not connected
n.c.	J2	-	not connected
n.c.	J3	-	not connected
n.c.	J5	-	not connected
n.c.	J6	-	not connected
n.c.	J11	-	not connected
n.c.	J12	-	not connected
n.c.	J14	-	not connected
n.c.	K2	-	not connected
n.c.	K5	-	not connected
n.c.	K6	-	not connected
n.c.	K11	-	not connected
n.c.	K12	-	not connected
n.c.	K15	-	not connected
n.c.	L3	-	not connected
n.c.	L6	-	not connected
n.c.	L7	-	not connected
n.c.	L8	-	not connected
n.c.	L9	-	not connected
n.c.	L10	-	not connected
n.c.	L11	-	not connected
n.c.	L12	-	not connected
n.c.	M6	-	not connected
n.c.	M7	-	not connected
n.c.	M8	-	not connected
n.c.	M9	-	not connected
n.c.	M10	-	not connected
n.c.	M11	-	not connected



Name	Ball	IO	Not Connected (n.c.) Pins
n.c.	M14	-	not connected
n.c.	N3	-	not connected
n.c.	N4	-	not connected
n.c.	N5	-	not connected
n.c.	N14	-	not connected
n.c.	P1	-	not connected
n.c.	P5	-	not connected
n.c.	P6	-	not connected
n.c.	P13	-	not connected
n.c.	P14	-	not connected
n.c.	P16	-	not connected
n.c.	R14	-	not connected
n.c.	R15	-	not connected
n.c.	R16	-	not connected

Table 11: Pin Description of not connected Pins



7 Package Dimensions

Package: FBGA 256 balls, 1.0mm pitch, size 17mm x 17mm, industrial temperature range 0°C . . . 85°C, RoHS compliant.




Figure 17: FBGA256 Package Outline

FBGA256 Package Dimensions in mm			
	min.	typ.	max.
A	-	-	2.20
A1	0.30	-	-
A2	-	-	1.80
A3	0.70 REF		
D	17.00 BSC		
E	17.00 BSC		
b	0.50	0.60	0.70
e	1.00 BSC		

JEDEC MS-034, Variation: AAF-1

Table 12: Package Outline Dimensions

©2016 TRINAMIC Motion Control GmbH & Co. KG, Hamburg, Germany

Terms of delivery and rights to technical change reserved.

Download newest version at www.trinamic.com

 Read entire documentation.



8 Supplemental Directives

8.1 Producer Information

8.2 Copyright

TRINAMIC owns the content of this user manual in its entirety, including but not limited to pictures, logos, trademarks, and resources. © Copyright 2016 TRINAMIC. All rights reserved. Electronically published by TRINAMIC, Germany.

Redistributions of source or derived format (for example, Portable Document Format or Hypertext Markup Language) must retain the above copyright notice, and the complete Datasheet User Manual documentation of this product including associated Application Notes; and a reference to other available product-related documentation.

8.3 Trademark Designations and Symbols

Trademark designations and symbols used in this documentation indicate that a product or feature is owned and registered as trademark and/or patent either by TRINAMIC or by other manufacturers, whose products are used or referred to in combination with TRINAMIC's products and TRINAMIC's product documentation.

This Datasheet is a non-commercial publication that seeks to provide concise scientific and technical user information to the target user. Thus, trademark designations and symbols are only entered in the Short Spec of this document that introduces the product at a quick glance. The trademark designation /symbol is also entered when the product or feature name occurs for the first time in the document. All trademarks and brand names used are property of their respective owners.

8.4 Target User

The documentation provided here, is for programmers and engineers only, who are equipped with the necessary skills and have been trained to work with this type of product.

The Target User knows how to responsibly make use of this product without causing harm to himself or others, and without causing damage to systems or devices, in which the user incorporates the product.

8.5 Disclaimer: Life Support Systems

TRINAMIC Motion Control GmbH & Co. KG does not authorize or warrant any of its products for use in life support systems, without the specific written consent of TRINAMIC Motion Control GmbH & Co. KG.

Life support systems are equipment intended to support or sustain life, and whose failure to perform, when properly used in accordance with instructions provided, can be reasonably expected to result in personal injury or death.

Information given in this document is believed to be accurate and reliable. However, no responsibility is assumed for the consequences of its use nor for any infringement of patents or other rights of third parties which may result from its use. Specifications are subject to change without notice.

8.6 Disclaimer: Intended Use

The data specified in this user manual is intended solely for the purpose of product description. No representations or warranties, either express or implied, of merchantability, fitness for a particular purpose



or of any other nature are made hereunder with respect to information/specification or the products to which information refers and no guarantee with respect to compliance to the intended use is given.

In particular, this also applies to the stated possible applications or areas of applications of the product. TRINAMIC products are not designed for and must not be used in connection with any applications where the failure of such products would reasonably be expected to result in significant personal injury or death (safety-Critical Applications) without TRINAMIC's specific written consent.

TRINAMIC products are not designed nor intended for use in military or aerospace applications or environments or in automotive applications unless specifically designated for such use by TRINAMIC. TRINAMIC conveys no patent, copyright, mask work right or other trade mark right to this product. TRINAMIC assumes no liability for any patent and/or other trade mark rights of a third party resulting from processing or handling of the product and/or any other use of the product.

8.7 Collateral Documents & Tools

This product documentation is related and/or associated with additional tool kits, firmware and other items, as provided on the product page at: www.trinamic.com.



9 Figures Index

1	Hardware FOC Application Diagram	6	9	Encoder ABN Timing	17
2	Hardware FOC Block Diagram	6	10	Hall Sensor Angles	18
3	SPI Timing	7	11	nPolePairsNumberOfPolePairs	19
4	SPIdatagramStructure	8	12	PID Architectures and Motion Modes	22
5	nPolePairsNumberOfPolePairs	11	13	Inner FOC Control Loop	23
6	Integer Representation of Angles with 16 Bit as s16 resp. u16	11	14	FOC Transformations	24
7	ADC Selector and Scaler with Offset Correction	14	15	Motion Modes	24
8	ABN Incremental Encoder N Pulse any- where between 0° and 360°	16	16	BBM Timing	26
			17	FBGA256 Package Outline	97



10 Tables Index

1	Order codes	4	8	Functional Pin Description	88
2	TABspiTimingParameter	7	9	Functional Pin Description	90
3	Numerical Representations	9	10	Supply Voltage Pins and Ground Pins	93
4	Examples of u16, s16, q8.8, q4.12	10	11	Functional Pin Description	96
5	Examples of u16, s16, q8.8	12	12	Package Outline Dimensions	97
6	Register Map for TMC4670	85	13	IC Revision	102
7	Pin Type Definition	86	14	Document Revision	102



11 Revision History

11.1 IC Revision

Version	Date	Description
V0.90	2016-JUN-30	Preliminary release.
V0.99	2016-SEP-30	Engineering Sample Release.

Table 13: IC Revision

11.2 Document Revision

Version	Date	Description
V0.9	2016-MAY-23, LL	Initial version.
V0.9	2016-JUL-29, LL	First draft committed.
V0.91	2016-OCT-13, LL	Functional summary added, updated register set of TMC4670 0v99, ADC selector with scaling and offset correction added, Analog Encoder (AENC) selector with scaling and offset correction added,
V0.91	2016-OCT-19, LL	Pinning updated.
V0.91	2016-MOV-02, LL	Short Spec Block Diagram added.
V0.91	2016-MOV-04, LL	PID architecture and PID motion mode drawings added
V0.91	2016-MOV-07, LL	Functional description hierachies updated
V0.91	2016-MOV-08, LL	First version for www.trinamic.com

Table 14: Document Revision

